

## MARINE DIESEL ENGINE

MODELS: SD80,SP90,SD120,SP135,SP160,SP225

# OPERATORS MANUAL AND PARTS IDENTIFICATION

Price \$7.50

THIS MANUAL IS AVAILABLE IN SEVERAL DIFFERENT LANGUAGES.  
PLEASE CONTACT YOUR NEAREST LEHMAN COMPANY FOR AVAILABILITY.

**Lehman Power Corporation**

800 E. Elizabeth Avenue  
Linden, New Jersey 07036  
United States of America  
(201) 486-5700  
Telex: 6853185

Cable: Lehman Linden

**Lehman Power Ltd.**

Saxham, Bury St. Edmunds  
Suffolk IP28 6QZ, England  
(44) 284-63100

Telex: 81133 Manns G

Dear Engine Owner:

Welcome to the growing family of Lehman Power Marine diesel engine users. You'll be happy to know that you have chosen an engine which is heartily endorsed by leading boat builders for its quality, performance, fuel economy and long life. Your engine is simple but highly efficient. Its power, stamina and fuel economy will amaze you - especially if you've previously operated gasoline power.

To obtain the best performance and the longest life from any machine, it must be serviced properly and regularly. Filters should be changed, coolant checked, oil changed at specified times, etc. Follow the suggested schedule shown herein - it will add to your boating safety, economy and enjoyment.

Perhaps the most important single recommendation I can make to the new engine owner is "do not tinker"! If the unit is running well - leave it alone! Adjustments and repairs should be performed only by a competent diesel mechanic who has the proper knowledge and tools. Many times we are requested to assist an owner who has attempted his own repairs. Unless you know what you're doing, please keep your hands off!


Lehman has a world-wide Service Network of Distributors and Dealers. Get to know your local one through the Lehman Start Up Program and they will be on hand to help you, should you need it.

Finally, always insist on genuine Lehman Parts. There are many examples of good boating days ruined by the use of spurious engine and cooling circuit parts. Always specify Lehman parts. If you have difficulty in obtaining them, please contact Lehman.

With proper care your Lehman Power engine will provide many hours of care-free boating. Thanks for the confidence you have shown in our Company by selecting our equipment. You will not be disappointed.

LEHMAN POWER CORPORATION

*Alvin H. H. H.*  
President



## Forward

This book contains operating and maintenance instructions for the complete range of engines listed on the inside front cover.

The life of your engine unit and the delivery of the high performance built into it will depend on the care it receives throughout its life. It is the owners' responsibility to ensure that the engine is correctly operated and that the maintenance operations outlined in this book are carried out regularly after the specified hours of operation have been reached. We consider it in your best interests to enlist the aid of the authorized Lehman Power Distributor in your area not only when repairs are required, but also for regular maintenance with genuine Lehman parts. This regular maintenance will result in minimal operating and repair costs.

Where the terms left and right appear in this book, they refer to the respective sides of the engine when viewed from the rear (flywheel end). Pistons and valves are numbered from the front or timing cover end of the engine, commencing with number 1 cylinder.

You may find that your engine assembly includes optional equipment not specifically covered in this manual. If you have any questions, contact your local Lehman Distributor.

## Before Operation

Before operating a new engine it should be thoroughly inspected for damage likely to affect its subsequent operation that may have occurred during shipment or during installation in the boat. Controls should be inspected to assure they perform and, of course, the operator should be familiar with all controls, instruments and proper engine operation, as well as, insuring that all fluids are at their proper capacities.

## Start Up Program

With this new range of engines, Lehman Power is initiating an "engine start up" program in many areas. This program consists of an installation inspection and we ask that owners follow the recommendations of the local Lehman distributor to ensure the maximum efficiency and pleasure is obtained from your Lehman diesel. Neither Lehman Power nor its distributors and dealers will be responsible for any travel and transportation costs associated with this program. These costs would be paid by the owners. Please contact your local Lehman Power distributor for more details concerning this subsidized program in your area. If this program is not yet available in your area, we suggest the engine not be started until the operator has read this manual thoroughly and familiarized himself with the manner of checking the engine oil level, coolant level, transmission oil level, etc. The chapters on "maintenance" and "running in" should be particularly noted.

NOTE: BEFORE STARTING TURBOCHARGED OR TURBO/INTERCOOLED ENGINES, REFER TO "LUBRICATION" SECTION FOR INFORMATION REGARDING PRIMING OF THAT TURBO UNIT WITH OIL.

## Running In:

DO NOT OPERATE YOUR NEW ENGINE AT HIGH SPEEDS IMMEDIATELY: EXCESSIVE WEAR OR DAMAGE MAY RESULT.

Long and dependable service may be expected if proper care is taken during the "break-in" period. The following speed limitations are recommended;

<u>Running Time</u>	<u>RPM</u>
30 Min.	Idle (no load)*
30 Min.	800
1 Hour	1000
1 Hour	1200
2 Hours	1400
4 Hours	1500

Total - 9 Hours


After the first 15 hours, complete the maintenance instructions as shown elsewhere in this manual.

\*Turbo and Turbo Intercooled Engines will produce some white smoke during this phase, it is normal, particularly on a new engine, and will disappear when the engine starts to work and gets warm.




Do not operate your engine for excessive periods at low power - your engine wants to work - let it!

### MODEL IDENTIFICATION AND SERIAL NUMBERS


The model and serial number of your engine is easily located by reference to the following drawing. The Lehman Power serial number, necessary for warranty authorization and control, will be stamped on a raised pad on the expansion tank. A date code will be stamped on a pad located behind the injection pump. The cubic inch displacement of the unit is stamped on a similar pad at the rear, starboard side of the cylinder block.



# Installation drawings and power curves



Super 90 DIN 6270



Standard 80 DIN 6270

## Specification Lehman Standard 80 and Super 90

TYPE — 4 cyl in line, 4 cycle overhead valve naturally aspirated diesel engine.

BORE/STROKE — 4.22 ins x 4.524 ins; 107 mm x 115 mm.

DISPLACEMENT — 254 cu ins; 4.150 litres.

GROSS POWER — Standard 80-80 bhp at 2500 rpm. Super 90-90 bhp at 2600 rpm.

COMPRESSION RATIO — 16.1:1

FUEL — ASTM D975 Class 2D or BS2869 Class A1.

OIL CAPACITY — 9.9 US quarts; 10.5 litres.

OIL FILTER — full flow, disposable cartridge, spin on.

FUEL SYSTEM — in line fuel injection pump, engine oil lubricated, with mechanical governor, and flexible braided fuel supply line.

ELECTRICAL SYSTEM — 12 volt or 24 volt negative ground.

STARTING MOTOR — 12 volt or 24 volt, electrical solenoid.

ALTERNATOR — 70 amp with voltage regulator.

RAW WATER COOLING SYSTEM — tubular copper or cupro-nickel heat exchanger with zinc anti-corrosion pencil; optional 80% or 100% keel cooling.

RAW WATER PUMP — gear driven high flow rubber impeller type.

FRESH WATER COOLING SYSTEM — pressurised fresh water circuit for engine and exhaust manifold.

FRESH WATER CAPACITY — 14.1 US quarts; 15 litres.

ENGINE MOUNTINGS — 4 in line or stepped, adjustable anti-vibration mounts; high grade on Super 90.

MAXIMUM INSTALLATION ANGLE — 15° rear down.

DRY WEIGHT LESS TRANSMISSION — 941 lbs; 428 kg.

EXHAUST OUTLET — 30° water cooled exhaust elbow, or straight dry exhaust flange.

TRANSMISSIONS — Borg Warner, Hurth, Newage PRM, Twin Disc — other available on request.

FINISH — Standard 80 all paint — Super 90 painted with chrome rocker box, air filter and filler caps.

APPROVAL STANDARDS — Lloyds, RINA, DNV, ABS and others available.

## Lehman Power Corporation

800 East Elizabeth Ave.

Linden, New Jersey 07036

Telex: 6853185 Cable: Lehman Linden

Tel: (201) 486-5700




## Lehman Power Limited

Saxham, Bury St. Edmunds


Suffolk IP28 6QZ, England

Tel: Bury St. Edmunds (0284) 63100

Telex: 81133 Manns G.



Standard 120 DIN 6270



Super 135 DIN 6270

## Specification Standard 120 and Super 135

TYPE — 6 cyl in line, 4 cycle overhead valve naturally aspirated diesel engine.

BORE/STROKE — 4.22 ins x 4.524 ins; 107 mm x 115 mm.

DISPLACEMENT — 380 cu ins; 6.22 litres.

GROSS POWER — Standard 120-120 bhp at 2500 rpm.

Super 135-135 bhp at 2600 rpm.

COMPRESSION RATIO — 16.1:1.

FUEL — ASTM D975 Class 2D or BS2869 Class A1.

OIL CAPACITY — Standard 120 14.2 US quarts; 15 litres — Super 135 14.6 US quarts; 15.5 litres.

OIL FILTER — full flow, disposable cartridge, spin on.

FUEL SYSTEM — in line fuel injection pump, engine oil lubricated, with mechanical governor, and flexible braided fuel supply line.

ELECTRICAL SYSTEM — 12 volt or 24 volt negative ground.

STARTING MOTOR — 12 volt or 24 volt, electrical solenoid.

ALTERNATOR — 70 amp with voltage regulator.

RAW WATER COOLING SYSTEM — tubular copper or cupro-nickel heat exchanger with zinc anti-corrosion pencil; optional 80% or 100% keel cooling.

RAW WATER PUMP — gear driven high flow rubber impeller type.

FRESH WATER COOLING SYSTEM — pressurized fresh water circuit for engine and exhaust manifold.

ENGINE MOUNTINGS — 4 in line or stepped, adjustable anti-vibration mounts; high grade on Super 135.

MAXIMUM INSTALLATION ANGLE — 15° rear down.

DRY WEIGHT LESS TRANSMISSION — 1254 lbs; 570 kg.

EXHAUST OUTLET 30° water cooled exhaust elbow, or straight dry exhaust flange.

TRANSMISSION — Borg Warner, Hurth, Newage PRM, Twin Disc — others available on request.

FINISH — Standard 120 all paint — Super 135 painted with chrome rocker box, air filter and filler caps.

APPROVAL STANDARDS — Lloyds, RINA, DNV, ABS and others available.

## Lehman Power Corporation

800 East Elizabeth Ave.

Linden, New Jersey 07036

Telex: 6853185 Cable: Lehman Linden

Tel: (201) 486-5700

## Lehman Power Limited




Saxham, Bury St. Edmunds

Suffolk IP28 6QZ, England


Tel: Bury St. Edmunds (0284) 63100

Telex: 81133 Manns G.

# Installation drawings and power curves



Super 225 BS AU 141 : 1971



Super 160 DIN 6270

## Specification Super 160 and Super 225

TYPE — 6 cyl in line, 4 cycle overhead valve diesel engine — Super 160 turbo charged and Super 225 turbo charged and intercooled.

BORE/STROKE — 4.125 ins x 4.524 ins; 105 mm x 115 mm.

DISPLACEMENT — 363 cu. ins; 5.95 litres.

GROSS POWER — Super 160-160 bhp at 2400 rpm; Super 225-225 bhp at 2450 rpm.

COMPRESSION RATIO — Super 160 15.45:1; Super 225 14.7:1.

FUEL — ASTM D975 Class 2D or BS2869 Class A1.

OIL CAPACITY — Super 160 14.6 US quarts; 15.5 litres — Super 225 19.8 US quarts; 21 litres.

OIL FILTER — full flow, disposable cartridge, spin on.

FUEL SYSTEM — in line fuel injection pump, engine oil lubricated, with mechanical governor and flexible braided fuel supply line.

ELECTRICAL SYSTEM — 12 volt or 24 volt negative ground.

STARTING MOTOR — 12 volt or 24 volt, electrical solenoid.

ALTERNATOR — 70 amp with voltage regulator.

RAW WATER COOLING SYSTEM — tubular copper or cupro-nickel heat exchanger with zinc anti-corrosion pencil; optional 80% or 100% keel cooling.

RAW WATER PUMP — gear driven high flow rubber impeller type.

FRESH WATER COOLING SYSTEM — pressurized fresh water circuit for engine and exhaust manifold.

FRESH WATER CAPACITY — Super 160 19.75 US quarts; 21 litres. Super 225 21.6 US quarts; 23 litres.

ENGINE MOUNTINGS — 4 in line or stepped, adjustable high grade anti-vibration mounts.

MAXIMUM INSTALLATION ANGLE — 15° rear down.

DRY WEIGHT LESS TRANSMISSION — Super 160 1275 lbs; 580 kg. Super 225 1310 lbs; 595 kg.

EXHAUST OUTLET — 30° water cooled exhaust elbow, or straight dry exhaust flange.

TRANSMISSIONS — Borg Warner, Twin Disc, PRM — others available on request.

FINISH — painted with chrome rocker box, air filter and caps.

APPROVAL STANDARDS — Lloyds, RINA, DNV, ABS and others available.

## Lehman Power Corporation

800 East Elizabeth Ave.  
Linden, New Jersey 07036  
Telex: 6853185 Cable: Lehman Linden  
Tel: (201) 486-5700

## Lehman Power Limited

Saxham, Bury St. Edmunds  
Suffolk IP28 6QZ, England  
Tel: Bury St. Edmunds (0284) 63100  
Telex: 81133 Manns G.



## LEHMAN POWER WARRANTY (LIMITED)

Lehman Power Corporation and Lehman Power Limited (hereinafter called "the Company") grant the following Limited Warranty to the first retail purchaser of Lehman Marine Engines in respect of which this Warranty is issued.

- 1 The Company warrants each new assembly or component part of our manufacture to be free from defects in material and workmanship for a period of one year from the date of purchase by the first retail purchaser. This Warranty is only initiated upon receipt by the Company of the completed Warranty Card, supplied with each new unit. Warranty service is obtainable from any authorized Lehman Power Distributor or Dealer. The Company reserves the right to repair or replace at our sole option any defective item.
- 2 In the event of any defect appearing in any part or parts in the list below within 12 months from the time when they are delivered new to the first retail purchaser thereof and the part or parts alleged to be defective are returned promptly to any authorized Lehman Distributor or Dealer the Company undertakes to have it or them examined, and should any defect due to faulty materials or workmanship be found on such examination to have it or them repaired or to have a replacement part or parts supplied Free of Charge. An allowance will be made for the labor normally involved in the removal of defective parts and the repair or replacement of these items, but this allowance will not include any additional work then required by reason of the type of equipment, the place or manner in which the engines are housed or installed. The allowance will be based on the direct labor times allowed by the Company to authorized Lehman Distributors or Dealers.
- 3 Parts repaired or replaced under terms of this Warranty are covered for the remaining part of the Warranty period.
- 4 This Warranty will not apply:
  - (a) If the defect is in any way due to the use of parts not made or approved by the Company.
  - (b) If the defect is in any way due to misuse, wrong application or neglect including poor servicing or bad storage when out of service.
  - (c) The articles are covered by a separate Warranty.
  - (d) If any identification numbers are altered or removed.
  - (e) If the goods are altered, modified or used in such a manner as to subject them to abnormal wear or strain.
  - (f) To engines which have been repaired or altered in a manner which in the Company's sole judgement may affect this performance or reliability.
  - (g) Failure resulting from improper installation of the engine and transmission.

5. Parts submitted for inspection will be scrapped upon completion of the claim unless prior arrangements were made to have them returned to the customer by the Lehman Distributor or Dealer.
6. Persons dealing with the Company's products are not the agents of the Company and have no authority to assume any obligations on its behalf.
7. For the purpose of this Warranty "owner" includes a person renting or leasing the goods for his own use under a lease purchase agreement.
8. The parts to which this Warranty applies are:
  - (a) Fresh water expansion tank
  - (b) Inlet and exhaust manifold
  - (c) Air filter
  - (d) Sea water pump
  - (e) Sea water/fresh water heat exchanger
  - (f) Sea water/transmission oil cooler if supplied by the Company
  - (g) Sea water/engine oil cooler
  - (h) Bell housing if supplied by Company
  - (i) Transmission drive plate if supplied by the Company
  - (j) Sea water pipes between the sea water pump output and the sea water outlet point
  - (k) Fresh water pipes for the engine cooling circuit, excluding any pipe-work feeding heating appliances fitted to the vessel and any defect arising therefrom which may affect the normal performance of the engine and its marinization
  - (l) Engine oil feed pipes and oil filter block
  - (m) Transmission oil feed pipes if supplied by the Company
  - (n) Engine stop solenoid if supplied by the Company
  - (o) Engine mounting brackets
  - (p) Engine flexible mountings if supplied by the Company
  - (q) Other parts such as instruments controls, etc. which may have been supplied by the Company at the request of the boatbuilders, but which do not habitually form part of the Company's contract with the boat-builder and which therefore cannot be itemized herein.
  - (r) Other parts which may be supplied by the Company from time to time
9. The complete base engine is warranted by the company.
10. The transmission is covered by its manufacturer's Warranty.
11. The Peugeot base engine is covered by the Warranty from Peugeot Motors Societe De Moteur C.L.M. through LPC/LPL.
12. The following services, expenses and conditions are not covered by Lehman Power Warranty.
  - (a) Damaged or loss related to shipping and handling.
  - (b) Towing charges, dockage, storage fees, telephone calls, fuel, loss of revenue, transportation charges (other than mileage and the mechanic's travel time), overtime pay, loss of or damage to any personal property and cost of lubricants and transmission fluids except when replacement or replenishment of fluids is required following a warranty repair.

- (c) Preparation costs related to warranty such as, moving furniture, bulk heads, deck plates, carpet, or any other equipment causing engine inaccessability.
  - (d) Failure caused by use of improper lubricant, overheating, or failure to follow recommended maintenance schedules as spelled out in the Lehman Power Manuals.
  - (e) Cost of repairs due to misuse, accident, neglect, racing and installation defects, as well as, shaft misalignment.
  - (f) Any consequential losses arising from failure of components under warranty.
13. All claims under the Warranty should be addressed to the nearest Lehman Distributor or Dealer. In the event that there is not a local authorized Distributor or Dealer, claims may be sent to:

Lehman Power Corporation  
 800 East Elizabeth Avenue  
 P.O. Box 647  
 Linden, New Jersey 07036-0647  
 U.S.A.

Tel: (201) 486-5658  
 Tlx: 138035 LehmanMfg

Lehman Power Limited  
 Saxham, Bury St. Edmunds  
 Suffolk, IP28 6QZ  
 England

Tel: 44-284- 63100  
 Tlx: 81133 Manns G.

#### WARRANTY CARD.

Every Lehman Diesel is supplied with a warranty card that must be completed in its entirety and returned to LPC, prior to initial start up. A facsimile of this card is shown below.

#### -----WARRANTY REGISTRATION INFORMATION-----

Engine Model \_\_\_\_\_ Serial No. \_\_\_\_\_ Date \_\_\_\_\_

Transmission Model \_\_\_\_\_ Serial No. \_\_\_\_\_ Ratio \_\_\_\_\_

Owners Name/Adress \_\_\_\_\_

Phone (\_\_\_\_) \_\_\_\_\_ Boat Name \_\_\_\_\_ Hull No. \_\_\_\_\_

Boat Home Port/Adress \_\_\_\_\_

Boat Mfgr. \_\_\_\_\_ Model \_\_\_\_\_ Length \_\_\_\_\_

Engine Purchased From \_\_\_\_\_

Address \_\_\_\_\_

\*NOTE: SERIAL NUMBER TO BE TAKEN FROM EXPANSION TANK ONLY.

## HOW TO USE THIS MANUAL

This manual is divided into sections as follows:

SECTION A - Page Nos. A1/on - General data, specifications, installation, adjustments, maintenance, etc. See index below.

SECTION B - Page Nos. B1/on - Parts identification of Ford base engines. See index on page B-1.

SECTION C - Page Nos. C1/on - Parts identification of Lehman Marine parts. See index page C-1.

In order to provide a simple method of identification, all models included herein have been assigned a "code" letter as follows:

ENGINE	CODE	CU/IN	NO. CYLS.	YEARS
M-Super	90	254	4	6/82-
N-Super	135	380	6	6/82-
O-Super	160	363	6	6/82-
P-Super	225	363	6	6/82-
Q-STD	80	254	4	6/82-
R-STD	120	380	6	6/82-

## INSTRUCTIONS FOR ORDERING PARTS

Parts listed in this manual may be ordered through any Lehman distributor or dealer or, in areas not served by a distributor/dealer, direct from the Lehman companies. Prices will be quoted upon request. In order to prevent errors, please order any required items by exact part number and name of part. When ordering parts, please advise model number and serial number of the engine.

## INDEX - SECTION A


Air bleeding the fuel system-----	A19
Before operation-----	A3
Bleeding the fuel system-----	A19
Break-in-----	A4
Controls-----	A16
Cooling system-----	A21,A22
Dimensions, engine-----	A6,A7,A8
Draining engine-----	A23,A35
Electrics-----	A25,A26
Fault-finding guide-----	A14
Filters, fuel & air-----	A20,A34
Fuel system-----	A17,A18,A19
Identification of models-----	A5,A12
Idling adjustment-----	A16,A34
Lift pump-----	A34
Lubrication system-----	A27,A28,A29
Maintenance-----	A31
Minor repairs-----	A32
Nameplate data-----	A5
Oil recommendations-----	A27

Power charts-----	A6,A7,A8
Running-in-----	A3,A4
Specifications-----	A6,A7,A8
Starting, stopping engine-----	A16
Tachometer take-off-----	A25
Timing the injection pump-----	A21
Transmission-----	A30
Trouble-shooting chart-----	A14,A15
Valve adjustments-----	A33
Vee belt-----	A33
Warranty-----	A9,A10
Water heater connection-----	A35
Winterizing-----	A35
Wiring diagram-----	A26

(copyright 1983 - LEHMAN POWER CORPORATION, Linden, New Jersey)

## LEHMAN DIESEL OWNER'S FAULT - FINDING GUIDE

\*Particular attention should be directed to the most common trouble-spots mark by an asterisk \*

ENGINE STARTS**ENGINE RUNS INTERMITTENTLY**

Idle Adjustment too low  
 \*Air - Leaking fuel system  
 Fuel (lift) pump diaphragm worn  
 Fuel tank near empty  
 Fuel filter (s) clogged  
 Sticking valves

**ROUGH IDLING**

\*Air in fuel system  
 \*Idle adjustment set too low  
 Dirty or faulty injectors  
 Injector pipes loose, cracked or broken  
 Incorrect injection timing  
 Restricted fuel filter  
 Faulty lift pump  
 Sticking valves  
 Broken valve springs

**ENGINE NOT DELIVERING FULL POWER**

**Air fuel system	Stop control partly engaged
Engine overheated	Sticking valve
Injection timing incorrect	Worn piston rings, or broken
Incorrect valve clearances	Faulty lift pump
Dirty air cleaner (s).	Restricted filters
Faulty injectors	
Faulty injection pump	

**ENGINE KNOCKS**

\*Air in fuel system  
 Oil level (pressure) low, worn bearings  
 Incorrect grade fuel oil  
 Incorrect injection timing  
 Faulty injector  
 Sticking valve or rocker arm  
 Piston slap

## FAULT - FINDING GUIDE (CONTINUED)

### ENGINE OVERHEATS

- \*Insufficient water supply
- Fresh water not circulating
  - a) Loose or broken vee belt
  - b) Hoses clogged or collapsing while running at high speed
  - c) Faulty thermostat
- \*d) Clogged heat exchanger
- e) Clogged bleed hole in thermostat
- Sea water flow insufficient
  - \*a) Clogged sea water strainer
  - b) Water intake scoop damaged or lost
  - c) Sea cock closed
  - d) Water pump impeller damaged
- \*e) Heat exchanger or oil coolers clogged.
- Low crankcase oil level
- Incorrect injection timing
- Engine needs top overhaul

### ENGINE EXHAUST SMOKES

- Fuel, poor grade (black smoke)
- Crankcase overfilled (blue smoke)
- Cold engine temperature (white or lite blue)
- \*Propeller too large (black smoke)
- Max. speed stop screw set too high for load (black smoke)
- Propeller too small (white smoke)
- Incorrect injection timing
- Faulty boost control unit

### ENGINE MISFIRES

- \*Injector pipe loose, broken or cranked
- Injectors dirty
- \*Air leaking in fuel system
- Sticking valve or rocker arm
- Sticking piston rings
- Engine needs top overhaul

## CONTROLS, STARTING & STOPPING ENGINE


No amount of engineering ingenuity or care in manufacture can substitute for the need of knowledge on the operation and avoidance of mis-use by the operator. It is important to be familiar with all controls so as to know how to properly operate your engine.

Refer Fig. 1. To stop engine, the stop lever should be moved as far as it will travel towards the front of the engine and held until engine is fully stopped. This lever cuts off the supply of fuel to the injection pump. (NOTE: before shutting down engine it should always be allowed to idle for about two minutes, particularly after extended periods of cruising - This is particularly important with Turbo and Turbo Intercooled engines).

Engine speed control is the longer lever at side of injection pump (Fig. 1.) Moving toward front of engine increases engine speed.

An excess fuel device permits additional fuel to be supplied by the injection pump to assist in starting the engine from cold. This device is fully automatic in operation.

Note: Some engines are equipped with an electric shut down solenoid. To stop engines that are equipped with this shut down, press stop button until engine stops running, then release button.



Fig

**Injection Pump Controls**  
1. Stop Lever  
2. Speed Control Lever

### STARTING ALL NATURALLY ASPIRATED ENGINES

To start engine when cold - make certain that transmission is in neutral position and that all boat accessory equipment (bilge pump, extra alternator or generator, hydraulic pump, winch, etc.) is disengaged. Check that engine stop lever is fully towards rear (flywheel end) of engine. Set throttle lever to  $\frac{1}{4}$  open position. Press starting button to operate starter. As soon as engine starts, release starting button and reduce speed control lever to warm-up (idling) speed of 700-800 RPM. If engine fails to start within 5 seconds, release starting button. Try again after allowing sufficient time for all moving parts to stop. Once engine has started, it should be allowed to reach 170°F before full load is applied.

To restart engine when warm, use same procedure as above except set speed control lever to approximately mid-point of its travel.



## STARTING ALL TURBOCHARGED ENGINES

Serious damage to the turbocharger bearing can result from inadequate lubrication if the following recommendations are now observed.

Prior to the first start after a turbocharger has been newly installed or if for any reason the oil supply to the turbocharger has been disconnected, you should insure that the turbocharger housing is filled with engine oil before reconnecting the oil feed pipe. In these circumstances, or in cases where the engine is being started for the first time after an oil change or after a period of 4 weeks or more without use, the following procedure must be used;

- 1) Engage either manual or electric stop control
- 2) Crank the engine with the starter motor for 15 seconds
- 3) Disengage stop control
- 4) Start engine in normal fashion and allow to idle for 30 seconds minimum before applying load

This ensures an adequate oil supply to the turbocharger bearing. The engine should be allowed to idle, without load, for 2 minutes prior to shut down to enable the oil to dissipate the heat from the turbocharger bearing.

## STOPPING ALL ENGINES

The engine should be allowed to slow idle for approximately 2 minutes before stopping, especially after extended periods of full load and full speed operation. This is particularly important in the case of turbocharged engines.

## FUEL SYSTEM

CAUTION: Your injection pump is a very accurately machined piece of equipment and requires careful handling and adjustment. No repairs other than shown herein should be entrusted to other than a diesel repair facility having the required tools, knowledge and test/calibration equipment.

CAUTION: Never bend the injector pipes (which connect injection pump to injectors) as this may unbalance the volume of fuel delivered to each cylinder.

CAUTION: Do not use a galvanized fuel tank as the zinc coating reacts with the fuel oil and forms undesirable compounds which can foul the injection system.




FIG. 2.

## ENGINE FUEL SYSTEM

- A - Excess fuel collector tube
- B - Secondary fuel filters
- C - Connector, excess fuel return line
- D - Injection pump cover

## FUEL SYSTEM (CONTINUED)

The fuel injection equipment is made to very accurate limits and therefore, even the smallest particle of dirt entering the system will destroy its efficiency by causing blockage or scoring or premature wear on highly finished parts. A clean fuel system is absolutely essential. Insure scrupulous cleanliness when handling fuel or fuel system components. At all times make certain that water is not allowed to contaminate the fuel oil. Try to make a practice of refueling out of the rain. Use a fine gauze filter funnel and always wipe the fuel tank around the filter cap before and after filling and immediately replace the cap.

An efficient, large size primary fuel filter and water separator (coalescer) is deemed a necessity in order to prevent foreign particles reaching the injection equipment on your engine.

Your engine is equipped with secondary fuel filters which filter out contaminants that may find their way through the primary filter. These filters (see Fig. 2,3,4 & 5) located towards rear of engine block, right side, have elements which should be replaced once each season or at least each 200 hours (which ever comes first) under normal conditions. (When replacing filters, use new gaskets or sealing rings to prevent air leaks.) Following filter replacement, bleed air from fuel system as later described under "bleeding the fuel system". Excess fuel delivered to the injectors by the injection pump is collected by a tube located under the rocker arm cover (see A, Fig.4) and delivered to fitting C, Fig. 4 located at rear, right side of cylinder head. This fitting should be connected to top of fuel tank by  $\frac{1}{4}$ " (min.) fuel line. It is recommended that the Boat Builders install a short section of flexible tubing in this line to prevent breakage due to engine vibration.




FIG. 3.

TYPICAL FUEL SYSTEM, NATURALLY ASPIRATED ENGINES

- A - Primary fuel filter & water separator
- B - Secondary fuel filter
- C - Excess fuel return tube
- D - Injection pump return tube

## FUEL SYSTEM (CONTINUED)




FIG. 4.

TYPICAL FUEL SYSTEM, TURBO ENGINES

A - Injection pump return tube

\*NOTE: "ON ENGINES MADE IN LATE 1983 ONWARDS-  
FUEL RETURN LINES MAY BE INTERCONNECTED  
TO SIMPLIFY PIPING"

## BLEEDING THE FUEL SYSTEM

Bleeding air from the fuel system may well be one of the important procedures to be learned by the operator. Air in the injection system may cause erratic engine performance, "missing" on one or more cylinders, reduced power, stop fuel from reaching engine and prevent or cause hard engine starting.

It must be remembered that the lift pump draws fuel from the tank, so any accumulation of air in the fuel system makes all connections, filters, etc. between fuel lift pump and tank suspect. In any new installation one must "bleed" the system of air for, obviously, air will be in the new fuel lines, filters, etc. If the fuel tank should run dry, bleeding will be needed when the boat is refueled. Bleeding will also be required after changing fuel filter elements. (Time and effort may be saved if filter is charged with fuel by removing the bleed plugs on top and slowly pouring fuel into the filter until it overflows.) Occasionally, after an extended run, an engine may slow down, or "miss", or lose RPM's or stop. Although there may be other causes, air in the fuel system should not be overlooked. Many times a tiny leak in a fuel line fitting may allow air to enter the system and accumulate until there is sufficient to cause the above mentioned symptoms.

## BLEEDING THE FUEL SYSTEM (CONTINUED)

To bleed system, follow this procedure;

1. Ascertain that there is sufficient fuel in tank, (Note; low fuel level may result in intake pipe being exposed due to "sloshing" of fuel, thus drawing air into system - try to keep your tanks topped up).
2. Make certain that fuel shut-off valve is turned on.
3. Loosen the bleed screw on the inlet side of the fuel filter (fig. 6&7) about two or three turns.
4. Operate the priming lever at the side of the fuel lift pump on naturally aspirated unit (fig. 7.) or the pump plunger (Fig. 6.) on turbocharged engines until a flow of fuel, free of air, is expelled. Then close screw.

No bleeding of the injection pump is required as these are fitted with a self purge device - which should be separately connected back to the top of the fuel tank in a similar manner to the spill return.

On Turbo Charged engines a third fuel return line from the pressure relief valve or the secondary filters is also connected direct to the fuel tank.




FIG. 5.

FUEL FILTER

A - Bleed screws

B - Replacable element




FIG. 6.

HIGH PRESSURE LIFT PUMP (ALL TURBO ENGINES)




FIG. 7.

FUEL LIFT PUMP - (ALL N.A. ENGINE)

A - Priming lever

## TIMING AND MAINTAINING THE FUEL INJECTION PUMP

The injection pump delivers an accurately metered quantity of fuel to each cylinder to suit any engines speed and load condition. The pump is a very accurately machined piece of equipment and requires careful handling and maintenance, which is beyond the scope of normal owner servicing. Since this pump should not require retiming except when being removed and reinstalled, and this is beyond the scope of normal owner servicing, the procedure will not be covered in this manual. Please contact your authorized Lehman Power distributor for this service. Warranty claims resulting from owner mishandling of the fuel injection pump will not normally be considered.

## COOLING SYSTEM

Your engine is cooled by the circulation of fresh water (contained in the system) through the water jackets surrounding the cylinders, cylinder head and exhaust manifold. The heated water flows by thermo-syphonic action, assisted by a pump at the front of cylinder block around the tubes of a "heat exchanger" located above the fuel lift pump on the star-board side of the engine. Raw water from outside the boat flows through the heat exchanger tubes, and the heat from the fresh water is thus transferred to the raw water which is expelled overboard. Please see Figures 8. and 9. . A Thermostat located in the cylinder head under the expansion tank on naturally aspirated units and in a separate unit on the star-board side of the turbo charged units promotes rapid warm up and maintains constant engine temperatures.

The fresh water system is filled through a cap atop the expansion tank at front of engine. Water level should be checked daily and maintained to the top of the aluminum pillar. These engines are fitted with a cooling system de-airation service and no bleeding of the manifold is required during system filling.

When filling cooling system, fill to top of aluminum pillar, then run engine for several minutes to insure system is completely filled. Add coolant as necessary.

The Fresh water system is pressurized by the cap atop expansion tank. When proper pressure is reached, excess water is expelled through the overflow tube under tank. Extreme care should be taken in removing cap while engine is hot. While engine is hot, if there is liquid in tank, the system may be refilled with safety; if not, allow engine to cool before refilling. Lehman Power recommends the use of anti-freeze at all times used in accordance with the manufacturer's recommendations. Ethylene Glycol based solutions are preferred, most of which includes various rust inhibitors. The use of "stop leak" type anti-freeze, which may still be available in some areas, is discouraged. If, for some reason anti-freeze solution is not being used in freezing temperatures, it is essential that the water systems be drained while engine stands idle and refilled before engine is restarted. Check water supply daily. Maintain level to approximately one-half inch below top of tank - The small "pillar" in the tank should just touch the water surface.

## COOLING SYSTEM (CONTINUED)

To assist in corrosion control, a zinc pencil is installed in your heat exchanger. This zinc pencil is sacrificial....that is, the raw water will attack and "eat away" the zinc before attacking metal of the heat exchanger. It is suggested that the plug accommodating this pencil be removed each week while engine is in service in order to inspect zinc. Replace zinc element when required. Failure to install zincs when needed may cause serious damage to entire cooling circuit.

It will be noted that your heat exchanger has removable end caps to facilitate cleaning. Removing caps will allow access to end of the tube "bundle". To clean tubes use a 3/16" diameter wood dowel, with a "twisting" action rather than a hammering action. A small caliber firearms cleaning kit or similar small brush may be used. Do not use a metal rod which may rupture the copper tubings.




FIG. 8.

## FRESH WATER CIRCULATION SYSTEM




FIG. 9.

## RAW WATER CIRCULATION SYSTEM

## COOLING SYSTEM (CONTINUED)

FIG. 9. - RAW WATER CIRCULATION SYSTEM

- A - Intake scoop of standard marine design, minimum 1" NPT should be used for raw water inlet. Reduce to 3/4" NPT at pump. Recommended scoop has bars across opening to prevent entry of large pieces of foreign matter - Lehman part NO. EW-3 is preferred.
- B - Sea-cock should be 1" NPT minimum size, "gate" type that opens fully to allow full, unrestricted flow of water - Lehman part NO. EW-22 preferred.
- C - The use of an efficient, full-flow raw water strainer is strongly recommended to prevent clogging of pump and exchangers by weeds, etc. Lehman part NO. EW-102 preferred.
- D - If hose is employed for intake, same should be reinforced type of extra heavy construction to prevent collapse under powerful suction of raw water pump - Lehman can provide such hose if required.

### WINTERIZATION OF COOLING SYSTEM

Inboard type heat exchangers must be drained of raw water when exposed to freezing temperatures. Raw water, pump, water inlet piping and intake strainer should likewise be drained when subjected to extreme cold.

If however, the vessel is being permanently laid up for the duration of the cold weather, we recommend mixing an anti-freeze solution and running this solution through the sea water system with the engine idling until discharged from the exhaust. This insures the sea strainer, coolers, heat exchanger, even the muffler and exhaust system will be protected.

Drain points for the fresh water system will be found on the port side of each engine block, on the aft end of the exhaust manifolds and on the heat exchanger.

Raw water drains are found on both engine and transmission coolers, as well as, the heat exchanger. To drain raw water pump, loosen rear cover.

### "KEEL COOLING" SYSTEMS

In some cases the installation of a "keel cooling" system may be preferred to the standard "heat exchanger" previously discussed. This system employs a series of tubes mounted on the underside of the hull through which the engine cooling water is circulated. Such a system is beneficial when the boat is to operate in muddy or silt-laden areas, however, the cooling element does produce additional hull "drag" which could affect performance in faster boats and creates a potential hazard if tubes fracture or are struck by driftwood, etc.

Piping engine to keel cooler is quite simple. As shown in Fig. 10. the connection on underside (starboard) of expansion tank delivers hot water from engine to keel cooler. Cooled water from keel cooler returns to engine via connection on aft end of exhaust manifold. The use of 1 3/4" I.D. hose will simplify connections, however hose must be reinforced type to prevent collapsing under suction and care must be exercised when installing to avoid "kinks" or the possibility of chafing.

## "KEEL COOLING" SYSTEMS (CONTINUED)

Installations using a "wet" exhaust will require raw water systems as shown in Fig. 9., but omitting heat exchanger.

When dry exhaust is employed, it is possible to eliminate use of raw water pump. Upon special order, lube and transmission oil coolers of large size may be incorporated in the engine fresh water system. The addition of such coolers is shown in Fig. 11.




FIG. 10. FRESH WATER CIRCULATION SYSTEM  
(Keel Cooler Type)




FIG. 11. WATER CIRCULATION SYSTEM (Keel Cooler Type)  
WITH LUBE and TRANSMISSION OIL COOLERS IN  
FRESH WATER FLOW.



## TACHOMETER ADAPTER

A tachometer "take-off" is provided on the starboard side of all naturally aspirated engines as an extra cost option. There is no provision for mechanical tachometer hook-up on turbocharged engines. This adapter accommodates a standard marine tachometer cable with 7/8" - 18 adaptor nut. Tip of cable core should be .187" diameter. Cable turns on-half engine speed in counter-clockwise direction.

If mechanical tachometer is not used or if cable is disconnected with engine to be operated for any lengthy period, the take-off should be capped to prevent oil leakage. Suitable cap (or plug to close aperture if take-off assembly is removed) is listed in the parts section of this manual.

It is recommended that a mechanical type tachometer be used only if located relatively close to engine. If cable length exceeds 12 to 14 feet or if many bends are required, an electrical tachometer system should be considered as much less strain is placed upon the take-off assembly. Installations requiring two tachometers should always use electric instruments.

## ELECTRICS

The standard electrical system for Lehman engines is 12 volt, NEGATIVE GROUND. Under no circumstances should polarity be reversed even for an instant for serious damage to alternator may result.

For special applications, optional electrical systems are available in 12 volt insulated return, 24 volt negative ground and 24 volt insulated return configurations.

A vee belt drives the alternator from crankshaft pulley. (Note: maintain belt at proper tension - see "minor Repairs, Maintenance and Adjustments"). Alternator has been corrosion-treated and has built-in silicon rectifier and enclosed slip-ring design for safe, sparkless, trouble-free operation. Transistor type, sealed voltage regulator has no moving parts and requires no adjustments. Alternator is lubricant packed for life at time of assembly and therefore requires no external lubrication. All alternators are equipped with a tapping for connection to operate a matching electric tachometer. (see Fig. 13)

A special actuating switch located on side of engine block behind alternator automatically energizes the alternator from the battery when engine is started and oil pressure reaches 7 lbs. Battery is disconnected by this switch when the engine is stopped. This switch initiates operation of the alternator system without the need of a separate switch and precludes the possibility of the operator neglecting to turn the charging system on or off. If desired, electrical instruments such as oil gage, temperature gage, etc. may be wired to be automatically energized when engine is started.

The starter motor is located on the left side (rear) of engine and requires no attention beyond, maintaining the electric cable connections clean and tight, the commutator clean and brushes renewed when necessary.

The standard solenoid mounted on the starting motor is a heavy-duty type. It must mechanically engage the starter pinion with the ring gear on flywheel; then it must actuate an electric switch to energize the starting motor. As the solenoid is normally energized by a simple push-button located at some distance from the starter, relatively heavy gage wire is required to transmit the needed amperage. Using small gage wire can result in insufficient current reaching the starter solenoid, overheating of wires, insufficient travel of starter pinion and failure of engine to start.

## ELECTRICS (CONTINUED)

To assure adequate amperage reaching starter solenoid a "piggy-back" solenoid is provided with short, heavy-gage wires connecting the two solenoids. The new solenoid requires comparatively little amperage so smaller gage wiring is required for connection to pushbutton.

The accompanying diagram indicates basic wiring requirements. Make certain that all connections are clean and tight. Locate battery as close as practical to the starter. Gage of battery cables will be dependent upon length, but should be NO. 0 minimum. Use No. 12 gage or heavier wire for balance of system. Electrical gages which require low current draw may be wired to oil pressure energizing switch indicated by "X" on the diagram.




FIG. 12.  
WIRING DIAGRAM

Note: Wiring diagrams of all standard applications are available from Lehman on request.




FIG. 13.

## LUBRICATION SYSTEM

The engine lubricating system is of the forced feed type, the oil being circulated by an oil pump mounted within the crankcase. The pump draws oil from the sump through a metal gauze screen and through an oil gallery on the port (left) side of engine which is tapped for installation of oil pressure gauge, low oil pressure alarm, or other such devices. Constant oil pressure is maintained by means of a relief valve situated in the pump. Oil under pressure passes through the oil filter where it is cleaned prior to being circulated inside the engine. The filter is a full-flow, disposable "spin-on" type. It should be replaced at each oil change, and is readily available from your Lehman dealer.

All marine installations should include an oil pressure gauge to register the lube system pressure and such gauge should be frequently checked to insure that system is functioning correctly. Normally the registered pressure should remain constant for a given engine speed. If pressure reading suddenly varies or fluctuates, the reason should be determined at once, otherwise severe damage may occur. As it is difficult to maintain a constant watch on engine gauges, the use of an audible warning system to sound a buzzer in case of low oil pressure (or high engine temperature) is strongly recommended - Lehman has kits EK31 and EK31A available - contact your dealer.

When engine is first installed, provide the proper quantity of oil as indicated under "specifications" section. The oil cap is located on top of engine rocker are cover. After pouring in oil, it will be necessary to wait several minutes before the oil level is checked in order to allow time for oil to flow to sump. Another fill cap which leads directly to sump is located on sump near front of engine. Run engine for several moments, shut down and check level on dipstick (see Fig. 14.). If oil level measurement is different from the "full" mark on dipstick, a new mark should be scratched or filed at the correct level. Another method is to measure the distance between the new full level and the factory full mark on the dip stick, remove the dipstick tube from the sump, and cut that distance off the tube. After deburring and reinstalling the tube the dipstick will be lowered into the oil, thereby retaining the factory markings. Of course, the above procedure applies only to 6 cylinder N.A. and turbo units with dipstick at front of sump. Four cylinder models with stick at rear of sump, require scratching the appropriate marks. These procedures are necessitated by differing installation angles.

When measuring oil level in regular usage in all naturally aspirated engines it is preferable to check after the engine has stopped for a period of time, such as overnight. This allows the oil in the overhead valve system to drain back to the oil sump, permitting a more accurate measurement.

On all turbocharged engines the oil should be checked prior to starting. After several minutes, shut engine down, wait for oil to drain back for several minutes, then check and add as required.

Add engine oil of the type and viscosity as follows. Oil should meet Ford specification 2M-2C-1017A, API classification CC or equivalent.

## LUBRICATION SYSTEM (CONTINUED)





FIG. 14.  
ENGINE OIL DIPSTICK



Oil Viscosity Chart

FIG. 15.

**TURBO ENGINES:** API classification CD oils only must be used in turbocharged engines. Use of other oil result in reduced engine life and invalidate engine warranty.

Serious damage to turbocharger may result from inadequate lubrication. Upon starting, engine should be allowed to idle (1000 rpm maximum) for 30 seconds or more before applying load. Also allow engine to idle for at least two minutes before shut-down to dissipate heat from turbocharger bearings.

Turbocharger must be oil-primed under any one of the following conditions;

- \* After an oil change.
- \* If oil supply tube to turbocharger has been disconnected.
- \* If either the engine or turbocharger is newly installed.
- \* If no oil pressure registers on gage after a "dead crank" (cranking with stop control in operation) for 15 seconds. This test must be performed if engine has not been started for 4 weeks or more.

To oil-prime turbocharger;

- a) Check for sufficient oil in the engine sump but do not top-up at this time.
- b) Disconnect the oil feed tube at the turbocharger end and fill the housing with oil. Reconnect tube.
- c) Using suitable syringe, inject about 4 pints of oil (as used in engine sump) into oil gage connection of engine. Refit oil gage.
- d) Start engine, allowing 1 minute to idle before increasing speed.
- e) Stop engine and check sump oil level. Top-off if needed or drain off any surplus.

## LUBRICATION SYSTEM (CONTINUED)

Engine oil should be changed after the initial 15 hours of operation and at each 200 hours of operation thereafter. Run the engine until normal operating temperature is reached. Shut down engine and allow oil to return to sump for five to ten minutes. In most installations it will not be possible to drain sump by removing plug which is located at bottom of oil pan, for clearance to bilge of hull will be limited. A low-cost, suction type, hand operated sump pump is required. Available as an extra cost option is a Lehman approved, permanently mounted hand pump. This can be connected to the sump plug - installation permitting or....Remove the dip-stick tube and insert suction hose of pump, working same towards lower portion of sump. (Some operators find it advantageous to use a length of copper tubing to assure reaching low section of sump.) Pump oil into container and dispose of same ashore. Replace vent cap on sump. Refill crankcase to "full" mark on dipstick. Run engine for several minutes, shut down and recheck oil level. If required, add sufficient oil to bring up to full mark.

Lube oil filter element should be replaced at each oil change. The disposable element is simply unscrewed from its base by turning counter-clockwise on naturally aspirated engines it is possible to rotate the oil filter, or remove it from its bracket, thus minimizing the risk of oil spillage. Position a one-quart or larger container under filter before removal to catch oil from spilling into bilge. A new element is simply screwed onto the base with medium hand tightness. Under no circumstances should a wrench or excess pressure be used. When next starting engine, check filter for possible leaks or seepage, and tighten only sufficiently to prevent same.

## TRANSMISSION (CONTINUED)

As there is such a wide variety of transmissions available with Lehman diesels, it is not practical to cover all installations in this manual. However, due to the popularity of the Borg Warner transmission, the following information is offered for those models.

No attempt is made herein to instruct in the installation of engine in the boat. The prudent boat owner or operator will, before initially starting engine, check engine/shaft alignment, operate clutch control to make certain that lever fully travels to the full ahead or full reverse positions, that neutral position may easily and quickly be found, and, of course, check oil level.

The transmission is a self-contained, sealed unit with independent lubrication system. No external adjustments of any kind are required. A built-in oil pump supplies the required hydraulic pressure to provide effortless shifting and assures an adequate supply of lubricant to all moving parts. An oil cooler is provided in order to maintain proper oil temperature which should not exceed 190°F.

Automatic transmission fluid type A, suffix A is recommended for lubrication. Or, if desired, "Dexron" type fluid may be used. Before starting engine fill transmission to the full mark on the dipstick. Run engine for a minute or two at low speed (in order to fill oil lines, cooler, etc.) Then shut off engine and check oil level. Add sufficient oil to bring up to full mark. Transmission oil level should be checked each time the oil level in engine is checked. Change oil every 200 hours of operation or at least once each season under normal conditions; however, number of hours may vary depending upon severity and conditions of service. WARNER drain plug is a large "hex" plug located near bottom right side. Removal of this plug and a small plug on the bottom of the reduction housing will completely drain the transmission. On some models the cooler return hose may be fed into the plug at the bottom of the transmission. In these instances, remove the hose and rotate the brass elbow as required for draining. If information on any other transmission is required, please contact Lehman and such information will be forwarded to you.

WARNING: Once again we repeat --control cable or other mechanism for shifting transmission must have sufficient "throw" to shift the operating lever fully into both forward or reverse position. Unless shift lever is positively in forward, neutral or reverse, considerable damage may result. Transmission warranty is void if control lever is changed in any manner, or repositioned or if linkage or remote control does not have sufficient travel in both directions.

When ordering parts for your transmission be sure to specify both model and serial numbers as shown on identification tag.




FIG. 16.

WARNER TRANSMISSION

## MAINTENANCE

The importance of correct lubrication, periodic inspection and adjustment cannot be over-emphasized. On it will depend, to a very large extent, the service which your engine will deliver.

The heat exchanger of your engine is protected by a "zinc pencil" which should be inspected and replaced periodically as required. As the rate of electrolysis varies greatly in different areas, only experience will dictate how often inspections should be made.

For convenience lubrication and maintenance work has been divided into the following periods;

- A Daily
- B After first 15 hours running.
- C After every 10 hours running.
- D After every 50 hours running.
- E After every 200 hours running.
- F After every 400 hours running.

### SUMMARY OF REGULAR MAINTENANCE

Daily.....	Check engine and transmission oil levels. Check cooling water level.
After first 50 hrs of operation....	Change Engine oil and filter. Check belt tension and adjust if required. Check cleanliness of intake air filter. Check (exchanger) zinc pencil.* Check for fuel, lube oil or coolant leaks. Check all wiring connections, cables, etc. Check valve clearances, adjust if required
Every 200 hrs of operation.....	Check idling speed, adjust if required. Check exhaust components for leaks. Check condition of all coolant and oil hoses. Check all engine mount bolts. Replace raw water pump impellor.
Every 1200 hrs of operation.....	Flush cooling system. Replace anti freeze.
Every 1500 hrs of operation.....	Check end play of turbocharger rotating assembly.

## SUMMARY OF REGULAR MAINTENANCE (CONTINUED)

Every 3000 hrs of operation..... Remove and dismantle turbocharger - repair as required.

Every 3600 hrs of operation..... Replace thermostats.

\*Zinc pencil should be checked every 2 weeks, regardless of number of operating hours until owner determines how often zinc element must be replaced. Replace after 50% deterioration.

Injectors need not be serviced at regular intervals but rather, should be serviced after problem such as smoke, loss of power, hard starting, etc. develops and has been diagnosed.

## MINOR REPAIRS, MAINTENANCE AND ADJUSTMENTS

DUE TO REVISED HEAD GASKET, HEAD GASKET AND HEAD BOLT DESIGN RETORQUING OF CYLINDER HEAD IS NOT REQUIRED. AND MUST NOT BE ATTEMPTED.

TO ADJUST VALVE CLEARANCES: (Note...Adjustments should be made while engine is at normal operating temperature). Following removal of rocker arm cover and tightening of cylinder head bolts as described above, actuate the engine stop control lever so engine will not start and revolve crankshaft pulley, until numbers 1 and 6 valves (on 4 cylinder) or numbers 1 and 4 (on 6 cylinder) are opened by their respective rocker arms.

Insert the correct thickness feeler gage (as shown in the following table) between the valve stem cap and rocker arm of No. 3 inlet valve (on 4 cylinder) or No. 9 exhaust valve (on 6 cylinder) as shown in figure 25. Turn the valve clearance adjusting screw Fig. 18 until the feeler blade is lightly caught between the rocker arm and valve stem cap, but so that the blade can still be removed with light resistance.

Select the appropriate feeler blade and repeat the procedure for No. 8 exhaust valve (on 4 cylinder) or No. 12 exhaust valve (on 6 cylinder models).

Rotate the engine and following the sequence in the following table, adjust each of the remaining valves. Replace rocker cover, making certain that gasket is unbroken and correctly positioned. After running engine for a short while, check rocker arm cover gasket for possible oil leaks.

VALVE CLEARANCES (Engine at normal working temperature) - see specification section.



## SUMMARY OF REGULAR MAINTENANCE (CONTINUED)




FIG. 18.  
ADJUSTING VALVE CLEARANCE

1- Adjusting screw  
2- Feeler blade  
3- Rocker arm

4 Cylinder engines		6 Cylinder engines	
Valves Fully Open	Valves to Adjust	Valves Fully Open	Valves to Adjust
1 and 6	3 and 8	1 and 4	9 and 12
2 and 4	5 and 7	8 and 10	3 and 5
3 and 8	1 and 6	2 and 6	7 and 1
5 and 7	2 and 4	9 and 12	1 and 4
		3 and 5	8 and 10
		7 and 11	2 and 6

TO ADJUST VEE BELT TENSION: Loosen alternator mounting and adjusting strap bolts as per figure 19. Move alternator to adjust belt tension. Tension is correct when your thumb pressure on belt at a point between alternator or and water pump pulleys does not exceed 1/4". Tighten alternator mounting and adjustment strap bolts.





FIG. 19.  
BELT ADJUSTMENT

1- Adjusting bolts

## SUMMARY OF REGULAR MAINTENANCE (CONTINUED)

**INTAKE AIR FILTER:** The air filtering element(s) on all naturally aspirated engines is polyurethane foam which traps and holds dust and foreign matter which could be drawn into the engine and cause severe damage. Turbo Charged and Turbo/Intercooled engines only use a Mesh Screen.

By reason of the efficiency of the filter in trapping contaminants it is difficult to effectively clean the element. It is usually best to replace this low-cost item as occasion demands. Simply slide old element off its retaining screen and carefully stretch a new element into position. If cleaning is desired, wash in a mild detergent mixed in clear, sweet water. DO NOT wash in mineral spirits, varsol, gasoline, or any petroleum product.



INJECTION PUMP (All N.A. Engines)

- 1- Max. speed stop screw
- 2- Idling stop screw




FIG. 20.

INJECTION PUMP (Turb

- 1 - Speed control lever
- 2 - Max. speed stop screw
- 3 - Idling stop screw
- 4 - Idle damper screw

**TO ADJUST IDLING SPEED:** When properly serviced and after the initial "break-in" period, your engine should idle within a general range of 600 to 700 RPM; when new, idle speed may be somewhat higher.

Engine must be at normal operating temperature when making adjustments. With engine running, loosen the idle screw locknut (figure 20) which is on side of fuel injection pump (between pump and engine block). Adjust the idle speed screw until engine is idling at correct speed and then tighten locknut. Operate the throttle lever to make certain that same returns to same setting.

**Note:** if engine is new or cold, it may idle unevenly. Do not increase the idle speed setting to compensate. ON NO ACCOUNT SHOULD THE MAXIMUM SPEED STOP BE CHANGED.

**TO CLEAN FUEL LIFT PUMP:** Turn off fuel supply valve. Holding receptacle under pump to prevent spilling of fuel into bilge of boat, loosen the center bolt and remove cover and pulsator. Clean pump thoroughly and wash cover and pulsator in fuel oil. Replace parts carefully. It will be necessary to bleed fuel system. Check for possible leaks after starting engine.

**TO CHANGE SECONDARY FUEL FILTERS:** (note-making certain that the filter element (s) you will use is an EXACT replacement for the element you will remove, otherwise, air leaks into the fuel system may result). Unscrew the securing bolts on top of filter housing and remove filter bowls and elements. Discard elements and upper and lower sealing rings. Wash out the bowls and clean fuel oil but do not use a cloth for remaining lint may clog the fuel system. Carefully fit new sealing rings to the filter heads and bowls, assemble to the filter heads and replace and tighten securing bolts. It will now be necessary to bleed the fuel system of air as described in separate section. After running engine for a short time, check filters for possible fuel leaks.

## WINTERIZING

In preparation for freezing temperatures, anti-freeze should be provided in the fresh water system of your engine. Due to the high temperature of operation a high boiling point anti-freeze is demanded. Do not attempt to use alcohol or other non-permanent types and do not use any liquids containing "sealants". Zerex (produced by DuPont) is highly recommended. Consult the specification chart of your engine to determine its coolant capacity and add sufficient anti-freeze to bring within the limits of expected temperatures. Inboard type heat exchangers and oil coolers must be drained of raw (sea) water when exposed to freezing temperatures. Drain plugs will be found on bottom of heat exchanger and oil coolers and should be removed until all water has been drained. Raw water pump may be drained by loosening screws holding rear cover in position. Please refer to "cooling system" section of this manual for alternate winterizing method.

If boat is to remain in water while draining engine, of course, the intake water seacock must be closed prior to draining. Do not neglect to open seacock prior to starting engine.

NOTE: TO DRAIN FRESH WATER, REMOVE WATER FILLER CAP FROM TOP OF EXPANSION TANK ON FRONT OF ENGINE. DRAIN BLOCK BY OPENING PETCOCK ON PORT (LEFT) SIDE OF ENGINE IN CENTER, LOWER SECTION. REMOVE PLUG ON UNDERSIDE OF HEAT EXCHANGER (THE ONE NEAREST CENTER OF EXCHANGER) TO DRAIN WATER FROM EXCHANGER, EXPANSION TANK AND EXHAUST MANIFOLD. REPLACE FILL CAP ON TANK AFTER CLOSING PETLOCK AND INSTALLING PLUG IN HEAT EXCHANGER.

Remove air filter (s) and cover openings in manifold with plastic film held in place with masking tape. Seal off all other openings....air vent on top of rocker arm cover, vent on front end of sump and overflow and vent hole on injection pump. plug exhaust pipe to prevent entrance of moisture.

Make certain that all engine exterior surfaces are clean, dry and free of oil or grease; then spray complete engine with any good rust preventative compound.

Before restarting engine, remove all plastic seals, covers, exhaust plug, etc., and refit air filter (s) in place. Do not neglect to replace all drain plugs, tighten rear cover of raw water pump, and turn on seacock.

## **GALLEY HOT WATER CONNECTIONS**

It is common marine practice to utilize engine coolant passed through a hot water heater to provide domestic hot water. Connection to engine is made with Lehman Kit D1496. A coolant feed to the heater is made from the engine drain plug on the portside of block while the coolant return hose is attached to the forward, port side of the exhaust manifold.



# SECTION B

## PARTS IDENTIFICATION - BASE ENGINE

In order to provide a simple method of identification, all models included herein have been assigned a "code" letter as follows:

ENGINE	CODE	CU/IN	NO. CYLS.	YEARS
M-Super	90	254	4	6/82-
N-Super	135	380	6	6/82-
O-Super	160	363	6	6/82-
P-Super	225	363	6	6/82-
Q-STD	80	254	4	6/82-
R-STD	120	380	6	6/82-


For ease in locating part numbers, turn to the applicable page:

Bearings, main and rod-----	B6,B7,B8,B9,B10
Block, engine-----	B3
Camshaft-----	B11
Crankshaft-----	B6
Damper, crankshaft-----	B18,B19,B20
Filter, fuel-----	B26
Flywheel-----	See section "C"
Gasket kit, engine-----	B3
Head, cylinder-----	B12
Injection equipment:	
Injectors-----	B23
Pipes-----	B22
Pump-----	B21
Pistons-----	B8
Pulley, crankshaft-----	B18,B19,B20
Pump, fuel (lift)-----	B24,B25
Pump, oil-----	B27
Pump, water-----	B33
Starting motor-----	B35,B36
Sump (oil pan)-----	B31,B32
Tools-----	B2
Turbocharger-----	See section "C"
Valves-----	B14

By reference to the drawings on the applicable page, select the required part and note the "key" number assigned to it. The key number will be repeated in the first column of a following page. The second column will indicate the engine to which the part applies per the engine code letters shown above. The third column shows the quantity required per engine.

## SERVICE TOOLS


8A1 WRENCH FOR FUEL INJECTION PIPE NUTS  
(TOP OF INJECTION PUMP)




8A2 SOCKET TOOL - DELIVERY VALVE HOLDER



8A6 TAPPET WRENCH-FLEX FUEL LINE to LIFT  
PUMP (NOT SHOWN)




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
12	ALL	6/8	1568855	SCREW	
13	M/Q	1	6102562	GASKET	
	N/R/O/P	1	6102563	GASKET	
14	ALL	4/6	1798506	SLEEVE	



<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M/Q	1	1788868	ROCKER ARM SHAFT	
	N/R/O/P	2	6085961	ROCKER ARM SHAFT	
2	ALL	2/4	6089082	WASHER	
3	ALL	2/4	3424956	BOLT	
4	ALL	2	3416839	PLUG	
5	ALL	2	6116098	ARM SUPPORT	
6	ALL	2/4	6093618	ARM SUPPORT	
7	ALL	1	6093619	ARM SUPPORT	
8	ALL	5/7	1599911	BOLT	
9	ALL	5/7	1575329	LOCK WASHER	
10	ALL	4/6	1745333	SPRING	
11	ALL	4/6	6084185	LEFT HAND ARM	
12	ALL	4/6	6084186	RIGHT HAND ARM	
13	ALL	8/12	6079714	VALVE TAPPET	10/81 - 4
	ALL	8/12	6118749	VALVE TAPPET	5/82 - 1
	ALL	8/12	6125498	VALVE TAPPET	11/82 -
14	ALL	8/12	6086866	ROD	
15	ALL	8/12	1504134	SCREW	
16	ALL	4/6	6093968	VALVE (EX)	10/81 - 1
	ALL	4/6	6133082	VALVE (EX)	1/83 -
17	ALL	4/6	6093969	VALVE (IN)	10/81 - 1
	ALL	4/6	6133084	VALVE (IN)	1/83 -
18	ALL	8/12	1789728	VALVE SPRING CAP	
19	ALL	4/6	1542662	SPRING EXHAUST	
20	ALL	4/6	1717773	SPRING INLET	
21	ALL	8/12	1543300	VALVE GUIDE STD.	
	ALL	8/12	6089288	VALVE GUIDE O/S	







<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M/Q	1	6082059	BLOCK ASSEMBLY	
	N/R	1	6079410	BLOCK ASSEMBLY	
	O	1	6079405	BLOCK ASSEMBLY	
	P	1	6079407	BLOCK ASSEMBLY	
2	M,Q,	1	6104215	GASKET KIT (OVERHAUL)	(B)
	N,R,	1	6104217	" " "	"
	O	1	6104222	" " "	"
	P	1	6104223	" " "	"
3	M,Q,	1	6104227	GASKET KIT (ENGINE DE-	(B)
	N,R,O,	1	6104229	" " CARBONISING)	(A) "
	P	1	6104228	" " " "	"
4	M,Q,	1	6104224	GASKET KIT(OIL PAN&FRONT	"
	N,R,O,	1	6104226	" " COVER)	"
	P	1	6104225	" " " "	"
5	M,Q	1	6104236	GASKET KIT (OIL PAN)	"
	N,R,O,	1	6104238	" " " "	"
	P	1	6104237	" " " "	"

(A) HEAD GASKET NOT INCLUDED MUST BE ORDERED SEPARATELY.


(B) NOT SHOWN.



<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M/Q	1	6086757	CYL BLOCK	
	N/R	1	6086780	CYL BLOCK	
	O	1	6086781	CYL BLOCK	
	P	1	6086760	CYL BLOCK	
2	O-P	6	6077156	CYL LINER 4.289"4.290	10/81-11/82
		6	6077157	CYL LINER 4.291"4.292"	10/81-11/82
	O/P	6	6128842	CYL LINER 4.289-4.290	11/82
	O/P	6	6128843	CYL LINER 4,290"-4291	11/82
	O/P	6	6128844	CYL LINER 4.291"-4.292	11/82
3	ALL	1	1788928	CAM BEARING 2.33-2.31	
	ALL	1	1788931	CAM BEARING 2.35-2.33	
4	ALL	3	6048528	PLUG--2.18"	
		3	6048527	PLUG--2.20"	
5	ALL	A/R	6102931	PLUG--1.680"	
6	ALL	1	6107198	DISTRIBUTOR APERTURE	
7	ALL	1	1788927	TAPPET OIL GALLERY	
8	ALL	1	1503090	OIL GALLERY PLUG	
9	ALL	2	1551172	OIL GALLERY PLUG	
10	M/Q	10/14	1788352	CRANK SHAFT BEARING CAP BOLT	
	N/R	10/14	1788352	CRANK SHAFT BEARING CAP BOLT	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>
10	O	10/14	1788352	CRANK SHAFT BEARING CAP BOLT	
	P	10/14	1788352	CRANK SHAFT BEARING CAP BOLT	
11	ALL	2	1790306	PIN	
12	ALL			PART OF BLOCK ASSEMBLY	
13	ALL	1	1465471	WATER DRAIN TAP	




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARKS
1	M,Q	1	6077423	CRANKSHAFT	(A)
	M,Q	1	1606655	CRANKSHAFT	(B)
	N,R	1	6077425	CRANKSHAFT	(A)
	N,R	1	1606657	CRANKSHAFT	(B)
	O,P	1	1512271	CRANKSHAFT	
2	M,Q	1	6106301	CRANKSHAFT MAIN BEARING SET	STD
	N,R	1	6106304	CRANKSHAFT MAIN BEARING SET	
	O,P			CRANKSHAFT MAIN BEARING SET	
	M,Q	1	6106224	CRANKSHAFT MAIN BEARING SET	-.010
	N,R	1	6106227	CRANKSHAFT MAIN BEARING SET	
	O,P			CRANKSHAFT MAIN BEARING SET	
	M,Q	1	6106229	CRANKSHAFT MAIN BEARING SET	-.020
	N,R	1	6106232	CRANKSHAFT MAIN BEARING SET	-.020
	O,P			CRANKSHAFT MAIN BEARING SET	

For footnotes turn to page B10




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARK
2	M,Q	1	6106306	CRANKSHAFT MAIN BEARING SET	-.030
	N,R	1	6106309	CRANKSHAFT MAIN BEARING SET	-.030
	O,P	1	6106312	CRANKSHAFT MAIN BEARING SET	-.040
	M,Q	1	6106315	CRANKSHAFT MAIN BEARING SET	-.040
	N,R	1	6106315	CRANKSHAFT MAIN BEARING SET	-.040
3	O,P	1	6106285	CRANKSHAFT THRUST WASHER	STD
	ALL	1	6106286	CRANKSHAFT THRUST WASHER	+.0025
	ALL	1	6106287	CRANKSHAFT THRUST WASHER	+.005
	ALL	1	6106288	CRANKSHAFT THRUST WASHER	+.0075
	ALL	1	6106289	CRANKSHAFT THRUST WASHER	+.010
	ALL	1	6106290	CRANKSHAFT THRUST WASHER	+.015
	ALL	1	6106291	CRANKSHAFT THRUST WASHER	
	ALL	1	6106292	CRANKSHAFT THRUST WASHER	
	ALL	1	6106293	CRANKSHAFT THRUST WASHER	
	ALL	1	6106294	CRANKSHAFT THRUST WASHER	
	ALL	1	6106295	CRANKSHAFT THRUST WASHER	
	ALL	1	6106296	CRANKSHAFT THRUST WASHER	




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARK
3	ALL	1	6106297	CRANKSHAFT THRUST	+.020
			6106298	WASHER	
4	ALL	1	6105490	CRANKSHAFT OIL SEAL	
5	ALL	1	6090885	WOODRUFF KEY	
6	ALL	1	1599715	CRANKSHAFT GEAR	(C) BL
			1599714	CRANKSHAFT GEAR	(D) YE
			1599713	CRANKSHAFT GEAR	(E) RE
7	M,Q	4	6103030	PISTON,PIN,RING ASSEMBLY	STD.
	N,R	6	6103030	PISTON,PIN,RING,ASSEMBLY	STD.
	O	6	1599870	PISTON,PIN,RING,ASSEMBLY	STD.
	P	6	6100051	PISTON,PIN,RING,ASSEMBLY	STD.
	M,Q,N,R	4/6	6103031	PISTON,PIN,RING,ASSEMBLY	+.015
	M,Q,N,R	4/6	6103032	PISTON,PIN,RING,ASSEMBLY	+.035
	M,Q,N,R	4/6	6103033	PISTON,PIN,RING,ASSEMBLY	+.055
8	M,Q,N,R	4/6	1599871	PISTON RING KIT	STD.
	O,P	6	1599879	PISTON RING KIT	STD.
	M,Q,N,R	4/6	1599872	PISTON RING KIT	+.015
	M,Q,N,R	4/6	1599873	PISTON RING KIT	+.035
	M,Q,N,R	4/6	1599874	PISTON RING KIT	+.055

For footnotes turn to page B10



<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
9	M,Q,N,R	4/6	6077162	PISTON PIN	
	O,P	6	6077163	PISTON PIN	
10	M,Q,N,R	8/12	1415288	SNAP RING	
	O,P	12	60-77164	SNAP RING	
11	M,Q,N,R	4/6	6088942	CONNECTING ROD	STD. (AAB)
	M,Q,N,R	4/6	6088943	CONNECTING ROD	.003 (ABB)
	M,Q,N,R	4/6	6088944	CONNECTING ROD	.006 (ACB)
	M,Q,N,R	4/6	6088945	CONNECTING ROD	.009 (ADB)
	O,P	6	6088946	CONNECTING ROD	STD. (GAB)
	O,P	6	6088947	CONNECTING ROD	.003 (GBB)
	O,P	6	6088948	CONNECTING ROD	.006 (GCB)
	O,P	6	6088949	CONNECTING ROD	.009 (GDB)
12	M,Q,N,R	4/6	1497464	CONNECTING ROD	
	O,P	6	6078059	BUSHING	
13	ALL	8/12	1447624	BOLTS	
14	ALL	8/12	1428387	PIN	
16	M,Q,N,R	8/12	6101141	CONNECTING ROD BEARINGS	STD.


For footnotes turn to page B10




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARK
16	O,P	6	6101142	CONNECTING ROD BEARINGS	STD. UPPER
		6	6101141	CONNECTING ROD BEARINGS	STD. LOWER
	M,Q,N,R	8/12	6101143	CONNECTING ROD BEARINGS	-.010
	O,P	6	6106203	CONNECTING ROD BEARINGS	-.010UP
		6	6101143	CONNECTING ROD BEARINGS	-.010LO
	M,Q,N,R	8/12	6106200	CONNECTING ROD BEARINGS	-.020
	O,P	6	6105660	CONNECTING ROD BEARINGS	-.020UP
		6	6105656	CONNECTING ROD BEARINGS	-.020LO
	M,Q,N,R	8/12	6105657	CONNECTING ROD BEARINGS	-.030
	O,P	6	6105661	CONNECTING ROD BEARINGS	-.030UP
		6	6105657	CONNECTING ROD BEARINGS	-.030LO
	M,Q,N,R	8/12	6105658	CONNECTING ROD BEARINGS	-.040
	O,P	6	6105662	CONNECTING ROD BEARINGS	-.040UP
		6	6105658	CONNECTING ROD BEARINGS	-.040LO
17	ALL	6	1599712	NOZZLE	
18	ALL	6	1541955	SEAL	

(A) TO BE USED IN ENGINE WITH GREEN DATA PLATE  
 (B) TO BE USED IN ENGINE WITH LIGHT BLUE DATA PLATE  
 (C) TO BE USED WITH 6103310 CAMSHAFT GEAR  
 (D) TO BE USED WITH 6103311 CAMSHAFT GEAR  
 (E) TO BE USED WITH 6103312 CAMSHAFT GEAR






<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M,Q	1	6112042	CAMSHAFT	1081-0982
	M,Q	1	6129243	CAMSHAFT	0982-
	N,R	1	6112043	CAMSHAFT	1081-0982
	N,R	1	6129244	CAMSHAFT	0982-
	O,P	1	6112044	CAMSHAFT	1081-0982
	""""	1	6129245	CAMSHAFT	0982
2	ALL	1	1794742	FRONT CAMSHAFT BEARING STD	
	ALL	1	1794743	FRONT CAMSHAFT BEARING STD	
3	ALL	3/5	1789333	CAMSHAFT BEARING STD	
	ALL	3/5	1789334	CAMSHAFT BEARING + .020	
4	ALL	1	1427085	CAMSHAFT THRUST WASHER	
5	ALL	1	1701616	PLATE CAMSHAFT THRUST	
6	ALL	1	1702841	LOCKING PLATE	
7	ALL	3	1568492	BOLT	
8	ALL	3	1575329	WASHER	
9	ALL	1	1793898	THRUST WASHER	
10	ALL	1	6103310	GEAR CAMSHAFT	BLUE
	ALL	1	6103311	GEAR CAMSHAFT	YELLOW
	ALL	1	6103312	GEAR CAMSHAFT	RED
11	ALL	1	1789748	KEY	
12	ALL	1	1487140	BOLT	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M/Q	1	6082577	CYLINDER HEAD	
	N/R	1	6082578	CYLINDER HEAD	
	O/P	1	6082579	CYLINDER HEAD	
2	M/Q	1	6103811	HEAD GASKET	
	N/R	1	6103813	HEAD GASKET	
	O/P	1	1602146	HEAD GASKET	
3	ALL	1	1788821	DOWEL	
4	M/Q/N/R	1	1790651	DOWEL	
	O/P	1	6077317	DOWEL	
6	ALL	1	1448568	PLUG	
7	ALL	17/25	6103719	BOLT	
8	ALL	1	6071651	CAP	
9	ALL	4/6	1430247	INLET VALVE SEAT STD	
	ALL	4/6	1430248	INLET VALVE SEAT +.010	
10	ALL	4/6	1430249	EXHAUST VALVE SEAT STD	
	ALL	4/6	1430250	EXHAUST VALVE SEAT +.010	
11	M,Q	1	6090236	VALVE COVER	
	N,R	1	6090237	VALVE COVER	
	O/P	1	6090238	VALVE COVER	






<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>
1	M,Q,N,R,O	1	6113977	TIMING GEAR HOUSING	
	P	1	6113978	TIMING GEAR HOUSING	
2	M,Q,N,R,O	1	6102560	GASKET	
	P	1	1599788	GASKET	
3	M,Q,N,R,O	1	6105291	COVER	
	P	1	6105292	COVER	
4	ALL	1	1599717	COVER	
5	M,Q,N,R,O	1	6102561	GASKET	
	P	1	1599789	GASKET	
6	ALL	1	6106840	SEAL	
7	ALL	1	1599790	SPACER	
8	ALL	1	6102559	SEAL	
9	ALL	1	1419959	SLEEVE STD.	
	ALL	1	1419960	SLEEVE .020 O/S	
10	ALL	1	1789541	PLUG	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
11	ALL	A/R	1508431	BOLT	
12	ALL	A/R	1568867	BOLT	
13	ALL	A/R	0241729	BOLT	
14	ALL	A/R	1571467	BOLT	
15	ALL	A/R	1579207	BOLT	
16	ALL	A/R	1575027	BOLT	
17	ALL	A/R	1584241	BOLT	
18	ALL	A/R	1602500	BOLT	
19	ALL	A/R	2579329	WASHER FLAT	
20	ALL	A/R	1444685	WASHER FLAT	
21	ALL	A/R	1436268	WASHER FLAT	
22	ALL	A/R	1459510	LOCKER WASHER	

## 5AA




## 6AA,7AA,6CA




<u>KEY</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	1	6091907	PULLEY	5AA for SD80,SP9 6AA,7AA,6CA for SD120, SP13 SP160, SP22
2	1	6086402	PULLEY	
3	1	6088051	PULLEY	
4	1	6091906	SPACER	
5	1	1617390	SPACER	
6	1	6091908	PULLEY	
7	1	6091909	PULLEY	
8	1	6119026	PULLEY	
9	1	1409531	HUB ASSEMBLY	
10	1	6059090	BOLT ASSEMBLY	

## 5AA




## 6AA,7AA,6CA




KEY	QTY	PART NO.	DESCRIPTION	REMARKS
11	4	1575330	BOLT	5AA for SD80,SP90
12	2	1568477	BOOT	
13	2	1760723	WASHER FLAT	
14	4	1444685	WASHER FLAT	6AA,7AA,6CA for SD120
15	1	6090806	WASHER (CRANKSHAFT DAMPER)	SP135
16	1	6090886	WASHER ASSEMBLY (DAMPER LOCKING)	SP160
17	1	6090808	BOLT	SP225
18	1	6090807	HUB (CRANKSHAFT PULLEY)	

## 5AA





## 6AA,7AA,6CA




<u>KEY</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
19	1	6090883	O RING	5AA for SD80,
20	1	6090884	O RING	6AA,7AA,6CA for SD
21	4	1489492	BOLT	SP
22	1	1556493	PULLEY	SP
23	6	1612348	BOLT	SP
24	4	1560616	LOCK WASHER	SP







<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	Q	1	6108556	FUEL INJECTION PUMP	
	R	1	6108563	FUEL INJECTION PUMP	
	M	1	6108557	FUEL INJECTION PUMP	
	N	1	6108562	FUEL INJECTION PUMP	
	O	1	6077209	FUEL INJECTION PUMP	
	P	1	6108567	FUEL INJECTION PUMP	
2	ALL	4	1575271	BOLT	
3	ALL	1	6062230	STUD	
4	ALL	5	1415664	WASHER	
5	ALL	1	1575009	NUT	
6	ALL	1	1719874	SEAL RING	
7	M,Q,N,R	1	6077521	GEAR	
	O,P	1	6114477	GEAR	
8	ALL	1	6077523	PLATE	
9	ALL	4	6057435	BOLT	
10	ALL	1	6108572	OIL TUBE	
	N-O-P	1		OIL TUBE	
11	O-P	1	6108571	TUBE ASSEMBLY	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M, Q	1	6105606	NO. 1 INJECTION LINE	
2	M, Q	1	6105607	NO. 2 INJECTION LINE	
3	M, Q	1	6105608	NO. 3 INJECTION LINE	
4	M, Q	1	6105609	NO. 4 INJECTION LINE	
1	N, R, O, P	1	6097948	NO. 1 INJECTION LINE	
2	N, R, O, P	1	6097949	NO. 2 INJECTION LINE	
3	N, R, O, P	1	6098078	NO. 3 INJECTION LINE	
4	N, R, O, P	1	6097950	NO. 4 INJECTION LINE	
5	N, R, O, P	1	6098081	NO. 5 INJECTION LINE	
6	N, R, O, P	1	6098082	NO. 6 INJECTION LINE	
7	ALL	A/R	1514329	LINE CLAMPS	
8	ALL	A/R	1514330	LINE CLAMPS	
9	ALL	A/R	1572059	SCREW	
10	ALL	A/R	6029099	LOCK WASHER	
11	ALL	A/R	1602234	FERRULE	
12	M	1	6113157	LEAK OFF PIPE	
	N-O-P	1	6113158	LEAK OFF PIPE	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>
13	ALL	1	1481753	CONNECTOR	
14	ALL	1	1514322	CONNECTOR	
15	M, Q, N, R	4/6	1599918	NOZZLE	
	O-P	6	1599919	NOZZLE	
16	ALL	A/R	1716286	BOLT	
17	ALL	A/R	1542666	SEAL	
18	ALL	A/R	1605353	SEAL	
19	ALL	A/R	1791101	NUT	
20	ALL	A/R	1707224	WASHER	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	M,Q,N,R	1	6038718	FUEL PUMP	
2	M,Q,N,R	2	6115328	STUD	
3	M,Q,N,R	2	1582108	NUT	
4	M,Q,N,R	1	1459154	PLATE	
5	M,Q,N,R	1	1789436	GASKET	
6	M,Q,N,R	1	2703732	ARM	
7	M,Q,N,R	1	1491104	ARM	
8	M,Q,N,R	1	1749177	PIN	
9	M,Q,N,R	1	1749182	SPRING	
10	M,Q,N,R	1	6039028	DIAPHRAM ASSEMBLY	
11	M,Q,N,R	1	6039027	SPRING	
12	M,Q,N,R	2	1749061	GASKET	
13	M,Q,N,R	2	1706711	VALVE ASSEMBLY	
14	M,Q,N,R	6	1472222	BOLT	
15	M,Q,N,R	6	1757975	WASHER	
16	M,Q,N,R	2	1791854	DIAPHRAM	
17	M,Q,N,R	1	1749047	COVER	
18	M,Q,N,R	1	1405313	SPRING	
19	M,Q,N,R	1	1563606	KIT	



<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	O-P	1	1536780	PUMP	FILTER ASSEMBLY PART NO. 6035908 FOR SP225 ONLY (Not Shown)
2	O-P	2	1472061	BOLT	
3	O-P	2	1459510	WASHER	
4	O-P	2	1596717	PLUNGER	
5	O-P	3	1596719	ADAPTOR	
6	O-P	3	6115328	STUD	
7	O-P	1	1444686	LOCK WASHER	
8	O-P	1	1568200	NUT	
9	O-P	1	1789436	GASKET	
10	O-P	1	1501698	GASKET	
11	O-P	2	1501527	ADAPTOR	
12	O-P	3	1503882	WASHER	
13	O-P	1	6005925	WASHER	




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARKS
1	ALL	1	6089149	FUEL FILTER ASSEMBLY	
2	ALL	2	1423477	FUEL FILTER ELEMENTS	
3	ALL	4	1422403	SEAL	
4	ALL	2	1760894	WASHER	
5	ALL	2	3416157	WASHER	
6	ALL	1	6119122	BRACKET	
7	ALL	2	1519781	STUD	10-81/05-8 2
		2	0201029	STUD	05-82
8	ALL	2	1568867	BOLT	
9	ALL	2	6089628	BUSH	
10	ALL	2	6034917	SEAL	
11	ALL	4	1470359	FLAT WASHER	
		4	1451781		
12	ALL	4	1465503	NUT	
		2	1465503		
13	ALL	1	6104604	VALVE ASSEMBLY	
14	ALL	1	+) )		PART OF 6104604
15	M,N,Q,R	1	3K776	TUBE ASSEMBLY	
	O,P	1	3K776	TUBE ASSEMBLY	
16	M,Q	1	6109580	TUBE ASSEMBLY	
	N,R,O,P	1	6109581	TUBE ASSEMBLY	
17	ALL	A/R	6107558	PLUG	



KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARKS
1	M,Q,N,R,O	1	6100762	OIL PUMP	(A)
	.....	1	6100763	" "	(B)
2	.....	2	1568869	BOLT	
3	.....	2	1560616	LOCK WASHER	
4	.....	1	6106323	ROTOR & SHAFT	(A)
	.....	1	6106324	" " "	(B)
5	.....	1	1793868	GEAR	(A)
	.....	1	1606389	"	(B)
6	.....	1	1606387	SPRING PIN	(A)
	.....	1	1606388	" "	(B)
7	.....	1	1605121	PLUNGER	(A)
	.....	1	6106331	"	(B)
8	.....	1	6106328	SPRING	(A)
	.....	1	6106329	"	(B)
9	.....	1	6106336	CAP	(A)
10	.....	1	1433211	PIN	(A)

(A) HOLBOURN EATON


(B) WHITEHEAD



<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
1	1	(A) 6100766	PUMP ASSEMBLY	
	1	(B) 6100767	PUMP ASSEMBLY	
2	2	1602210	STUD	SP225 ONLY
3	1	(A) 6106325	ROTOR & SHAFT ASSEMBLY	
	1	(B) 6106326	ROTOR & SHAFT ASSEMBLY	
4	1	(A) 6106327	THRUST PLATE	
5	1	(A) 1605121	PLUNGER (RELIEF VALVE)	
	1	(B) 6106331	PLUNGER (RELIEF VALVE)	
6	1	(A) 6106328	SPRING	
	1	(B) 6106330	SPRING	
7	1	(A) 6106336	CAP	
	1	(B) 6106337	CAP	


A-HOLBOURN EATON  
B-WHITEHEAD MOTORIDES






<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>REMARKS</u>
8	1	1602162	GASKET	SP225 ONL
9	3	1589154	BOLT	"
10	3	1444685	LOCKWASHER	"
11	1	6103491	TUBE ASSEMBLY	"
12	1	6089943	FLANGE	"


A-HOLBOURN EATON  
B-WHITEHEAD MOTORIDES




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>
1	P	1	6104937	ADAPTOR OIL FILTER	
2	P	2	6103880	CONNECTOR	
3	P	1	6108606	CONNECTOR	
4	P	4	1502540	BALL	
5	P	1	6103879	PLUG	
6	P	1	6103620	WASHER	
7	P	1	6103880	90 ELBOW	
8	P	3	OE407.5	BOLTS	
9	P	1	1612468	OIL FILTER	




<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>
1	N,R,O	1	1403431	OIL PAN	
	P	1	6106334	OIL PAN	
2	N,R,O	1	6104238	GASKET KIT OIL PAN	
	P	1	6104237	GASKET KIT OIL PAN	
3	ALL	1	1411447	TUBE	STD
	ALL	1	1411448	TUBE	O/S
4	ALL	1	1608307	CAP ASSEMBLY	
5	ALL	1	1708048	INSERT DRAIN PLUG	
6	ALL	1	1710927	WASHER	
7	ALL	1	1595292	PLUG OIL DRAIN	
8	N,R,O	1	1508092	OIL PUMP PICK UP TUBE & SCREEN	
	P	1	6087682	OIL PUMP PICK UP TUBE & SCREEN	
9	ALL	1	1538040	BOLT	
10	ALL	1	1560616	WASHER	
11	N,R	1	1788795	TUBE	
	O,P	1	6097108	TUBE	
12	N,R	1	1403432	DIP STICK	
	O,P	1	6090988	DIP STICK	
13	ALL	4	1401461	STUD	
14	ALL	A/R	6113951	WASHER LOCK	
15	ALL	4	1575009	NUT	
16	ALL	A/R	1568479	BOLT	
17	ALL	1	1A239	COVER APERTURE	
17a	ALL	1	1C28	COVER APERTURE GASKET	
18	ALL	1	OC31	LOCKWASHER	
19	ALL	1	OE201	BOLT	
20	ALL	1	OE290	PLUG ASSEMBLY	




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARK
1	M,Q	1	1509694	OIL PAN	
2	M,Q	1	6104236	GASKET KIT OIL PAN	
3	ALL	1	1411447	TUBE	STD.
	ALL	1	1411448	TUBE	O/S
4	ALL	1	1608307	CAP ASSEMBLY	
5	ALL	1	1708048	INSERT DRAIN PLUG	
6	ALL	1	1710927	WASHER	
7	ALL	1	1595292	PLUG OIL DRAIN	
8	M,Q	1	1508088	OIL PUMP PICK UP TUBE & SCREEN	
9	ALL	1	1538040	BOLT	
10	ALL	1	1560616	WASHER	
11	M,Q	1	1788795	TUBE	
12	M,Q	1	1791936	DIP STICK	
13	ALL	4	1401461	STUD	
14	ALL	A/R	6113951	WASHER, LOCK	
15	ALL	4	1575009	NUT	
16	ALL	A/R	1568479	BOLT	
17	ALL	1	1A239	COVER APERTURE	
17a	ALL	1	1C28	COVER APERTURE GASKET	
18	ALL	1	OC31	LOCKWASHER	
19	ALL	1	OE201	BOLT	
20	ALL	1	OE290	PLUG ASSEMBLY	



EY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARKS
1	M-N-Q-R	1	1602421	WATER PUMP	
2	O	1	1602418	WATER PUMP	
3	P	1	6089348	WATER PUMP	
4	ALL	A/R	1571467	5/16 / .75 BOLT	
	"	"	1568491	5/16 /1.0 BOLT	
	"	"	1568489	5/16 /1.0 BOLT	
	"	"	1568489	5/16 / 1.25 BOLT	
	"	"	1584477	5/16 / 1.75 BOLT	
	"	"	1572232	5/16 / 2.25 BOLT	
	"	"	1602361	5/16 / 3.50 BOLT	
	"	"	1405658	5/16 / 4.00 BOLT	
5	ALL	2	6102971	5/16 /1.77" STUD	
		A/R	6086189	5/16 /2.79" STUD	
		1	6102970	5/16 /2.83" STUD	
6	ALL	A/R	1575209	NUT	
7	M-N-O-Q-R	1	6091842	GASKET WATER	
8	P	1	6094370	GASKET WATER	




KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARKS
9	N-N-O-Q-R	1	1602430	IMPELLER	
10	P	1	6077199	IMPELLER	
11	ALL	1	6086162	SEAL	
12	P	1	6077206	BACK PLATE	
13	ALL	1	6084165	CAP	
14	M-M-O-Q-R	1	1602434	BEARING & SHAFT	
15	P	1	6077200	BEARING & SHAFT	
16	ALL	A/R	OC31	LOCK WASHER	
18	O-P	1	6089351	DUAL SHEAVE PULLEY	
19	M-N	1	1422360	PULLEY	
20	M-N	1	1602440	HUB	



<u>KEY</u>	<u>ENGINE</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	M,Q,N,R,O	1	6099841	STARTER MOTOR
2	M,Q,N,R,O	3	1605123	BOLT
3	M,Q,N,R,O	3	1451781	FLAT WASHER
5	M,Q,N,R,O	1	1527447	SOLENOID ASSEMBLY
6	M,Q,N,R,O	1	1470620	ARMATURE ASSEMBLY
7	M,Q,N,R,O	1	6104802	BOLT
8	M,Q,N,R,O	1	1517314	HARDWARE (KIT)
9	M,Q,N,R,O	1	1596362	DRIVE HOUSING (KIT)
10	M,Q,N,R,O	1	1517316	SOLENOID LINK (KIT)
11	M,Q,N,R,O	1	1517315	BRUSHES (KIT)
12	M,Q,N,R,O	1	1527241	DRIVE PINION (KIT)
13	M,Q,N,R,O	1	1596361	INTERMEDIATE BRACKET (KIT)
14	M,Q,N,R,O	1	1522092	BRAKE SHOES & SPRINGS (KIT)
15	M,Q,N,R,O	1	1517313	FIELD COIL (KIT)
16	M,Q,N,R,O	1	1527442	BRUSHES (KIT)
17	M,Q,N,R,O	1	1517321	BRUSH SUPPORTS (KIT)
18	M,Q,N,R,O	1	1522094	BRUSH SPRINGS (KIT)
19	M,Q,N,R,O	1	1527444	BRUSH END COVER (KIT)
20	M,Q,N,R,O	1	1517318	MOTOR SEALING (KIT)







KEY	ENGINE	QTY	PART NO.	DESCRIPTION	REMARKS
10	P	1	1523043	BRUSHES (KIT)	12V
	"	1	1602404	" "	24V
11	"	1	6104882	COVER ASSEMBLY	12V
	"	1	6104799	" "	24V
12	"	1	6104884	RESISTOR ASSEMBLY	12V
	"	1	6104883	" "	24V
13	"	1	6104885	FIELD COIL (KIT)	12V
	"	1	6104804	" " "	24V
14	"	1	6104888	PINION ASSEMBLY	12V
	"	1	6104810	" "	24V
15	"	1	6104290	" " (KIT)	
16	"	1	1523046	SEGMENTS & SPRINGS (KIT)	
17	"	1	1436394	SPRING	
18	"	4	1436382	SEGMENTS	
19	"		+0	(WITH# 13)	
20	"	1	6017846	RELAY ASSEMBLY	

(

(

(

# SECTION C


## INDEX TO LEHMAN MARINE EQUIPMENT

In order to provide a simple method of identification, all models included herein have been assigned a "code" letter as follows:

ENGINE	CODE	CU/IN	NO. CYLS.	YEARS
M-Super	90	254	4	6/82-
N-Super	135	380	6	6/82-
O-Super	160	363	6	6/82-
P-Super	225	363	6	6/82-
Q-STD	80	254	4	6/82-
R-STD	120	380	6	6/82-


Air filter. . . . .	page C4,C6,C14
Alarm system. . . . .	C51
Alternator, Motorola 72 AMP . . . . .	C44,C46
Aperature cover. . . . .	C50
Belt, vee . . . . .	C44,C46
Cooler, oil . . . . .	C24,C26,C28
Exchanger, heat . . . . .	C30,C32,C34
Fuel line (flexible). . . . .	C51
Manifold, 6 cylinder. . . . .	C2
Manifold, 4 cylinder. . . . .	C8
Manuals, instruction, shop, etc.. . . . .	C52
Miscellaneous . . . . .	C50,C51
Mountings, engine . . . . .	C50
Piping, fresh water . . . . .	C22,C24,C30,C32,C34
Piping, raw water . . . . .	C24,C26,C28
Pump, water . . . . .	C36,C37,C39
Solenoid, starter relay . . . . .	C50
Spare parts kits. . . . .	C50
Stop engine controls. . . . .	C43
Supports, engine. . . . .	C48
Tank, expansion . . . . .	C20,C22
Transmission & Adaption . . . . .	C49
Water heater connection kit . . . . .	C51
Fly Wheel Assembly . . . . .	C49

By reference to the drawing on the applicable page, select the required part and note the "key" number assigned to it. The key number will be repeated in the listing of parts following the drawing. The second column indicates the engine to which the part applies per the engine code letters shown above. The third column shows the quantity required per engine.




# 6 CYLINDER MANIFOLD

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	1A389	MANIFOLD BODY
2	1	3L14	PLUG 1/4 NPT
3	2	2D34	MANIFOLD GASKET
4	6	6087437	MANIFOLD STUD
5	6	1B59	BUSHING
6	1	1D55	LIFTING EYE
7	1	1C42	GASKET, WATER OUTLET
8	2	OC21	WASHER
9	2	OE107	BOLT
10	2	3K4	CLAMP
11	1	3K2133	HOSE
12	2	OE111	BOLT
13	2	OC21	WASHER
14	1	1A396	WATER OUTLET ADAPTOR
15	1	3L14	PLUG
16	4	OE102	BOLT
17	4	OC21	WASHER
18	1	1D52	BLANKING PLATE
19	1	1C38	GASKET
20	1	OC41	WASHER
21	1	OC41	WASHER
22	3	OE306.5	BOLT
23	2	OC41	WASHER
24	1	OC41	WASHER
25	1	OC41	WASHER
26	3	OE309	BOLT
27	1	3L40	PLUG
28	3	OE309	BOLT
29	2	OC41	WASHER
30	1	3L40	PLUG
31	4	OE317	BOLT
32	1	OC41	WASHER
33	1	1A411	WATER OUTLET FOR TURBO
34	2	OE104	SET SCREW
35	2	OE107	BOLT



PLENUM CHAMBER/AIR FILTER ASSEMBLY  
SD120/SPI35


<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	1A403	PLENUM CHAMBER
2		OE201	BOLT
3		OC31	WASHER
4	2	1C39	GASKET
5	2	1C401C44	GASKET
6	1	OC31	GASKET
7	4	OE206	WASHER
8	4	2H75	BOLT
9	1	2H75	AIR CLEANER, CHROMED
	1	2H76	AIR CLEANER
10	2	3K10	CLAMP
11	1	3K204A13	HOSE 13"
12	1	1E7	FOAM ELEMENT






PLENUM CHAMBERSP160

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	1A409	PLENUM CHAMBER
2	9	OE201	BOLT
3	9	OC31	LOCK WASHER
4	1	3E860	FERRULE
5	1	3E916	TUBE
6	2	1C39	GASKET
7	2	1C40	GASKET
8	4	OC31	LOCK WASHER
9	2	OE207	BOLT
10	2	OE206	BOLT
11	1	1A414	AIR INTAKE
12	1	1C44	GASKET
13	2	FP1486719	WASHER
14	2	FP1472481	PLUG



4 CYLINDER MANIFOLDSD80/SP90


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	MANIFOLD BODY	1A390
2	1	PLUG	3L40
3	4	BUSHING	1B59
4	2	GASKET, MANIFOLD	2D35
5	4	STUDS, MANIFOLD	6087437
6	1	LIFTING EYE	1D55
7	1	GASKET, WATER OUTLET	1C42
8	1	WATER OUTLET ADAPTOR MACHINED	1A396
9	2	WASHER	OC21
10	2	BOLT	OE107
11	2	CLAMP	3K4
12	1	HOSE	3K2133
13	2	BOLT	OE111
14	2	WASHER	OC21
15	1	PLUG	3L14
16	9	WASHER	OC41
17	1	BOLT	OE309
18	3	BOLT	OE306.5
19	1	PLUG	3L40
20	2	BOLT	OE309
21	3	BOLT	OE317



PLENUM CHAMBER / AIR FILTER ASSEMBLY


SD80/SP90

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	1A405	PLENUM CHAMBER
2	6	OE201	BOLT
3	6	OC21	WASHER
4	2	1C45	GASKET
5	1	1C44	GASKET
6	4	OC21	WASHER
7	4	OE206	BOLT
8	1	2H75	AIR CLEANER, CHROMED
	1	2H76	AIR CLEANER
9	1	3K10	CLAMP
10	1	3K204A13	HOSE 13#
	1	3K10	CLAMP
11	2	OE113	BOLT
12	2	OC21	WASHER



INTERCOOLER ASSEMBLYSP225

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2J30	INTERCOOLER BODY
2	2	2J31	END CAP
3	2	2J6	"O" RING
4	1	2J40	INTERCOOLER CORE
5	1	2J41	SUPPORT
6	2	1C39	GASKET
7	2	1C40	GASKET
8	1	3L1	PLUG
9	2	3K510	HOSE REDUCING
10	2	3K3B	HOSE CLIP
11	1	1D62	PIPE
12	6	OE202C	BOLT
13	2	OE208	BOLT
14	2	OE401	BOLT
15	3	OE201C	BOLT
16	11	OC31	LOCK WASHER
17	6	OC41	LOCK WASHER
18	1	1D64	PIPE ASSEMBLY
19	1	3L45	ADAPTOR
20	2	3L50	PLUG
21	2	3E40	ADAPTOR
22	4	3K3	HOSE CLIP
23	6	OE302	SET SCREW
24	2	OC51	LOCK WASHER
25	2	OC30	WASHER
26	2	OE104	SET SCREW
27	2	OC21	LOCK WASHER
28	10	3K220	HOSE
29	1	1D66	PIPE






# TURBO CHARGER ASSEMBLY

## SP160/SP225 ENGINE

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2J45	TURBO CHARGER HOLSET
2	1	1456626	HOSE
3	1	1456620	AIR CLEANER
4	2	5001144	CLAMP
5	1	1C52	OIL RETURN GASKET
6	4	OGC32	WASHER
7	2	OGC201C	SET SCREW
8	1	3E901	OIL RETURN ELBOW
9	4	6065049	CLAMP
10	2	6065027	HOSE
11	2	6065031	SLEEVE
12	1	6087966	TUBE
13	1	6097079	BANJO BOLT
14	2	1515382	WASHER
15	1	6087961	CONNECTOR OIL DRAIN
16	2	OB45	NUT
17	2	OD61	STUD
18	2	1C43	GASKET
19	1	3E903	OIL FEED PIPE
20	2	3E905	PLUG
21	1	3E910	ADAPTOR BLOCK
22	1	3E230	ADAPTOR
23	4	OC51	WASHER
24	2	OE408	BOLT
25	1	3E915	PLUG
26	1	3K790	VENT HOSE
27	2	OA3	SCREW
28	2	OC5	LOCK WASHER
29	2	2M6	CLIP
30	4	OGC32	WASHER
31	2	OGC207	BOLT
32	1	3L1	PLUG
33	1	3E912	OIL FEED BLOCK
34	1	1L53	OIL FEED GASKET
35	2	6065050	CLIP
36	1	2M9A	PIPE SUPPORT (NOT SHOWN ON DWG.) (FOR 19)
37	1	OB1	NUT
38	1	OC41	SPRING WASHER
39	7	3K215	HOSE (GOES WITH 35 TURBO TO INJ. PIPE)


} GOES WITH 36



TURBO EXHAUST ASSEMBLY

SP160/SP225 ENGINE


<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2J15	HEAT SHIELD
2	1	0GB28	NUT
3	1	0GC31	LOCK WASHER
4	1	1500785	STUD
5	1	2J23	GASKET
6	1	2J20	ADAPTOR
7	2	2J21	CLAMP
8	2	2J22	STEEL GASKET
9	1	2J19	RISER
10	1	3L2	PLUG 1/8"
11	1	3L52	PLUG
12	1	3K3	CLAMP
13	1	EW6424 24"	HOSE
14	1	3E859	ELBOW
15	1	2J18	EJECTION ELBOW
16	1	2J17	HEAT SHIELD



EXHAUST ASSEMBLY

SD80 / SP90 / SD120 / SP135


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	EXHAUST OUTLET	1A397
2	4	BOLT	OE403
3	4	LOCK WASHER	OC51
4	1	GASKET	1C43
5	1	ELBOW	3E856
6	2	CLAMP	3K2
7	1	HOSE	3K351



THERMOSTAT ASSEMBLY

SP160/SP225


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	HOSE	3K503
2	4	CLAMP	3K4
3	6	BOLT	OE101
4	6	LOCK WASHER	OC21
5	2	BOLT	OE202
6	2	LOCK WASHER	OC21
7	1	THERMOSTAT COVER	1A409
8	1	GASKET	1C47
9	1	RUBBER SEAL	1C46
10	1	THERMOSTAT, SP160/225	2C250
11	1	THERMOSTAT HOUSING	1A410
12	1	HOSE	3K2133



EXPANSION TANK ASSEMBLYSD80-120/SP90-135

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	1A393	HEADER TANK
2	2	OD71	STUD 2.75x5/16
3	2	OC31	WASHER
4	2	OB26	NUT
5	1	2C305	PRESSURE CAP 7 PSI
	1	2C304	PRESSURE CAP (CHROME)
6	2	3K2	CLAMP
7	1	3K823	HOSE
8	2	3E858	ELBOW
9	2	3K2	CLAMP
10	1	3K775	VENT HOSE
11	1	6071841	THERMOSTAT
12	1	1541317	GASKET
13	1	3C27	HOSE BARB
14	2	3K4	CLAMP
15	1	1D60	TUBE 4 CYLINDER
	1	1D50	TUBE 6 CYLINDER
16	1	3K824	REDUCING HOSE 4 CYLINDER
	1	3K2133	HOSE 6 CYLINDER
17	1	3K825	OVER FLOW HOSE

NOTE: COLD START SWITCH SHOWN ON LAST PAGE.






EXPANSION TANK ASSEMBLYSP 160 / SP 225

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	1A393	HEADER TANK
2	1	1A393	HEADER TANK
3	1	2C304	PRESSURE CAP
4	2	3K2	CLAMP
5	2	3E858	ELBOW
6	1	3K823	HOSE
7	1	3K775	VENT HOSE
8	1	1541317	GASKET
9	1	3C27	HOSE BARB
10	6	3K4	CLAMP
11	1	1D73	TUBE
12	1	3K2133	HOSE
13	1	3K2133	HOSE
14	1	3K825	HOSE, OVER FLOW
15	2	OD71	STUD
16	2	OC31	WASHER
17	2	OB26	NUT
18	1	3K826	T-REDUCING HOSE
19	1	3E860	ELBOW
20	1	3K2	CLAMP


NOTE: COLD START SWITCH SHOWN ON LAST PAGE.



ENGINE OIL COOLER


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	OIL COLLER, SD80	2C233
	1	OIL COOLER, SP90	2C233
	1	OIL COOLER, SD120	2C233
	1	OIL COOLER, SP135	2C233
→ 2	2	ADAPTOR	3G35
3	1	BRACKET, UPPER	2M3
4	1	LOCK WASHER	OC21
5	1	NUT	OB15
6	1	NUT	OB34
7	1	LOCK WASHER	OC41
8	1	NUT	OB34
9	1	LOCK WASHER	OC41
10	1	BRACKET	1D51
11	1	FILTER	<u>2N50</u>
12	1	NIPPLE	3C450
13	1	OIL BASE	1A395
14	1	BOLT	OE353
15	4	ADAPTOR	3G34
16	4	ADAPTOR	3G34
17	2	BOLT	OE300
18	1	OIL LINE	3K778
19	1	OIL LINE	3K779
20	2	LOCK WASHER	OC41
→ 21	2	ADAPTOR	3G35
22	2	BOLT	OE406
23	2	LOCK WASHER	OC51
24	1	OIL LINE	3K777
25	4	ADAPTOR	3G34
26	1	ADAPTOR, OIL FEED	1A391
27	1	GASKET	2D29
28	1	BRACKET, LOWER	2M4
29	1	BOLT	OE101

44pl 3G35




ENGINE OIL COOLERSP160

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2C228	ENGINE OIL COOLER
2	2	3G35	ADAPTOR
3	1	3K782	OIL HOSE ASSEMBLY
4	1	3K783	OIL HOSE ASSEMBLY
5	2	3K14	HOSE CLIP
6	1	3K816	HOSE
7	2	OD68	STUDS OIL FILTER ADAPTOR
8	2	1776462	GASKET
9	1	1A412	OIL FILTER ADAPTOR
10	2	OB46	NUT
11	2	1776462	STUDS OIL FILTER ADAPTOR
12	1	1582035	OIL FILTER BASE
13	2	OE403	SET SCREW
14	1	1582038	OIL FILTER
15	8	3K353	WATER HOSE
16	1	1A413	APLIT FLOW RETURN
17	2	3K12	HOSE CLIP
18	8	3K354	HOSE
19	1	OE307.5	SOCKET SCREW
20	2	OE302	SET SCREW
21	1	3L51	PLUG
22	2	3G37	ADAPTOR
23	4	OC51	LOCK WASHER
24	3	OC41	LOCK WASHER
25	2	3K2	HOSE CLAMP



ENGINE OIL COOLERSP225


<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	2	3K14	HOSE CLIP
2	1	1A413	SPLIT FLOW RETURN
3	1	2D36	GASKET
4	1	3K786	PIPE RUBBER
5	1	3K353	WATER HOSE
6	1	3K354	RADIATOR HOSE
7	3	3K12	HOSE CLIP
8	3	OC41	LOCK WASHER
9	1	OE307.5	SOCKET SCREW
10	2	OE302	SET SCREW
11	1	2C245	OIL COOLER ENGINE
12	2	3G38	ADAPTOR
13	1	3K784	OIL HOSE ASSEMBLY
14	1	3K785	OIL HOSE ASSEMBLY
15	1	3K209-2	
16	1	1G148	PIPE
17	1	OGE201	BOLT
18	1	OC30	FLAT WASHER
19	1	OGC32	LOCK WASHER
20	1	6089349	HOSE
21	2	3K15	HOSE CLIP
22	3	3K3A	HOSE CLAMP






HEAT EXCHANGER ASSEMBLYSD120/SP135

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2C232	HEAT EXCHANGER
2	2	OE303C	BOLT
3	1	OE302C	BOLT
4	6	OC41	WASHER
5	6	OC41	WASHER
6	1	1E44	BRACKET
7	2	OB35	NUT
8	6	OC41	WASHER
9	2	3K4	CLAMP
10	2	3K2133	HOSE
11	1	1D56	PIPE
12	2	2C306	SADDLE
13	2	3K4	CLAMP
14	1	3K503	HOSE
15	2	1B81	SPACER
16	1	1E45	BRACKET, LOWER
17	2	OC40	WASHER
18	2	OE303	BOLT
19	6	OC41	WASHER
20	1	OE370	BOLT
21	1	OE303	BOLT
22	2	2C307	STRAP
23	2	OE306.5	BOLT
24	2	2K2133	HOSE
25	2	3K4	CLAMP




HEAT EXCHANGER ASSEMBLYSD80/SP90

<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	HEAT EXCHANGER	2C242
2	1	HOSE 3"	3K2133
3	3	CLAMP	3K4
4	1	BRACKET, UPPER	1E46
5	2	BOLT	OE303
6	2	WASHER	OC41
8	2	NUT	OB35
9	2	WASHER	OC41
10	2	SADDLE	2C306
11	2	CLAMP	3K4
12	2	CLAMP	3K4
13	1	HOSE 3"	3K2133
14	1	TUBE	1D56
15	1	HOSE	3K503
16	2	SPACER	1B81
17	2	WASHER	OC41
18	2	BOLT	OE303
19	2	BOLT	OE204
20	2	WASHER	OC41
21	1	NUT	OB35
22	1	BRACKET, LOWER	1E47
23	2	LOCK WASHER	OC31
24	2	BOLT	OE302
25	2	STRAP	2C307
26	2	BOLT	OE306.5




HEAT EXCHANGER ASSEMBLYSP160 / 225

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2C246	HEAT EXCHANGER
2	1	10517	CLAMP
3	5	OC41	LOCK WASHER
4	2	OE310	BOLT
5	1	1D70	CLAMP, REAR
6	4	1C54	RUBBER STRIP
7	2	1C54	RUBBER STRIP
8	1	3L1	PLUG
9	2	1C54	RUBBER STRIP
10	4	3K12	HOSE CLIP
11	1	3K511	RADIATOR HOSE
12	18	1056	PIPE
13	1	3K2133	HOSE
14	2	OE303	SET SCREW
15	1	1D68	SUPPORT REAR
16	2	1D69	CLAMP SPACER
18	1	1058	SUPPORT FRONT
19	4	OE403	SET SCREW
20	1	1D67	CLAMP
21	4	OC51	LOCK WASHER
22	1	OE302	SET SCREW



SD80/SP90


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	JABSCO PUMP (LESS GEAR)	2C48
2	3	LOCK WASHER	OC41
3	1	NUT	OB34
4	1	ELBOW	3E858
5	2	CLAMP	3K2
6	1	HOSE	EW62
7	1	BOLT	OE302
8	1	LOCK WASHER	OC41
9	1	ELBOW	3E585
10	1	BOLT	OE302
11	1	LOCK WASHER	OC41
12	1	GEAR	2B102
13	1	GASKET	1C33
14	1	NUT	OB59
15	1	LOCK WASHER	OC61
16	1	KEY	SP1401-10




SD120/SP135

<u>KEY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	JABSCO PUMP (LESS GEAR)	2C48
2	LOCK WASHER	OC41
3	NUT	OB34
4	ELBOW	3E858
5	CLAMP	3K2
6	TUBE	1D59
7	HOSE 2"	3K207A2
8	BOLT	OE302
9	DRIVE GEAR	2B102
10	GASKET	1C33
11	WASHER	OC61
12	NUT	OB59
13	KEY	SP1401-10

Breakdown of 2C48 Pump




KEY	DESCRIPTION	QTY	MODEL
1	ENDCOVER BLANK	1	3992
2	CAM	1	490
3	CAM SCREW	1	SP1003
4	GEAR	1	-
5	WASHER	1	-
6	NUT	1	-
7	ENDCOVER SCREW	6	SP1002
8	GASKET	1	3298
9	IMPELLER	1	1210
10	BODY	1	10054-
11	WEARPLATE	1	7883
12	RETAINING RING	1	SP1700
13	SEAL	1	SP6080
14	SEAL SEAT	1	SP8022
15	CUP RUBBER	1	9722
16	BEARING HOUSING ASSEMBLY		
17	SPLINE SEAL	1	4345



KEY	DESCRIPTION	QTY	PART NUMB
1	SHAFT	1	10957
2	BEARING HOUSING	1	10959
3	SLINGER	1	3286
4	SEAL	1	SP2703-02
5	BEARING	2	SP2601-39
6	RETAINING RING	1	SP1700-24
7	KEY	1	SP1401-10
8	BOLT	1	SP1095-09
9	WASHER	1	SP1602-06
10	NUT	1	SP1105-03
11	BEARING SPACER	1	9998
12	SLEEVE	1	10958





KEY	QTY	DESCRIPTION
-----	-----	-------------


1	1	JABSCO PUMP (LESS GEAR)
2	3	LOCK WASHER
3	2	BOLT
4	1	GEAR
5	1	GASKET
6	1	LOCK WASHER
7	1	NUT
8	1	KEY
9	1	NUT
10	1	ELBOW

PART NUMBER
-------------

2C49
OC41
OE302
2B102
1C33
OC61
OB59
SP1401-10
OB34
3E859


## BREAK DOWN OF 2C49 PUMP

## PUMP HEAD




KEY	DESCRIPTION	QTY	PART NUMBER
1	ENDCOVER BLANK	1	3993
2	CAM	1	934
3	CAM SCREW	1	SP1004-09
4	BODY	1	10329-200
5	RETAINING RING	1	SP1700-62
6	SEAL	1	SP6080-07
7	SEAL SEAT	1	SP8022-07
8	SEAL CUP	1	9722
9	END COVER SCREW	6	SP1003-09
10	GASKET	1	890
11	SPLINE SEAL	1	4345
12	IMPELLER	1	920
13	WEARPLATE	1	4156
14	BEARING HOUSING see below		"BEARING HOUSING"
15	GEAR	1	11084
16	WASHER	1	11085
17	NUT	1	11086

## BEARING HOUSING



## BEARING HOUSING


KEY	DESCRIPTION	QTY	PART NUMBER
1	SHAFT	1	10957-01
2	BEARING HOUSING	1	10959
3	SLINGER	1	3286
4	SEALER	1	SP2703-02
5	BEARING	2	SP2601-39
6	RETAINING RING	1	SP1700-248
7	KEY	1	SP1401-10
8	BOLT	1	SP1095-09
9	WASHER	1	SP1602-06
10	NUT	1	SP1105-03
11	BEARING SPACER	1	9998
12	SLEEVE	1	10958



TRANSMISSION OIL COOLER

SD80/SP90/SD120/SP135


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	TRANS OIL COOLER	2C207
2	1	SPACER	1B81
3	1	BRACKET, UPPER	2M3
4	1	BOLT	OE101
5	2	CLAMP	3K2
6	1	HOSE	3K351
7	1	OIL LINE 22"	3K772
8	1	ELBOW	3D24
9	1	OIL LINE 17"	3K764
10	1	ADAPTOR BUSHING	3G25
11	1	BRACKET LOWER	2M4
12	1	LOCK WASHER	OC21
13	1	NUT	OB16
14	1	BOLT	OGE306
15	1	LOCK WASHER	OGC41
16	1	PLUG, DRAIN	3L1



SP160 / 225


OIL COOLER TRANSMISSION

<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2C243	TRANS OIL COOLER TWIN DISC ONLY
1	1	2C234	TRANS OIL COOLER
2	2	2M3	OIL COOLER BRACKET LOWER
3	2	0E401	SET SCREW
4	2	0B15	PLAIN NUT
5	2	0C21	LOCK WASHER
6	1	3K780	HOSE ASSEMBLY
7	2	3G35	ADAPTOR
8	1	3K781	HOSE ASSEMBLY
9	1	3K352	ELBOW
10	2	3K13	HOSE CLIP
11	2	0E101	SET SCREW
12	1	1D71	BRACKET
13	2	0B35	NUT
14	2	0C41	LOCK WASHER
15	2	2M4	OIL COOLER BRACKET UPPER
16	2	3G36	ADAPTOR




ALL ENGINES  
STOP SOLENOID

<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	SOLENOID	2E211
2	2	BOLT	OE101
3	1	CABLE CLAMP	EC104
4	2	BOLT 10/32	OA3
5	2	FLAT WASHER	OC20
6	2	LOCK WASHER	OC21
7	2	NUT	OB15
8	1	SWIVEL JOINT	3L43
9	1	NUT	OB15
10	1	ROD	1B79
11	1	NUT	OB15
12	1	BALL JOINT	EC103
13	1	COTTER PIN	2K353
14	1	WAVEY WASHER	OC23
15	1	FLAT COPPER WASHER	OC24
16	1	PIVOT	EC115
17	1	BRACKET	1B81
18	2	LOCK WASHER	OC5
19	2	NUT	OB1
20	1	LOCK WASHER	OC21
21	1	BOLT M10x20	OGE301
22	1	CAP SCREW	OE201
23	1	LOCK WASHER	OGC38



SP225


<u>KEY</u>	<u>QTY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1	2E7	ALTERNATOR 70 AMP
2	1	2E206	SWITCH
3	1	2E400	LINK WIRE ASSY
4	1	2E401	LINK WIRE ASSY
5	1	2B240	BELT, MATCHED SET
6	1	2M40	ADJUSTING ARM
7	1	OGC30	WASHER
8	1	OGC31	WASHER
9	1	OGE202	BOLT
10	2	OE201	BOLT
11	1	OE204	BOLT
12	3	OB26	NUT
13	5	OC31	LOCK WASHER
14	1	2M44	PIVOT BRACKET
15	1	2B25	TWIN PULLEY
16	1	OE202	BOLT
17	1	2E450	BLOCKING DIODE (NOT SHOWN)
18	1	2E406	TAIL WIRE (NOT SHOWN)



SD80/SP90/SD120/SP135


<u>KEY</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	1	ALTERNATOR, 70AMP.	2E7
2	1	BOLT	OGE202
3	1	LOCK WASHER	OGC31
4	1	FLAT WASHER	OGC30
5	1	ADJUSTING BRACKET	2M19
6	1	WASHER	OC31
7	1	NUT	OB26
8	2	LOCK WASHER	OC31
9	2	FLAT WASHER	OC30
10	1	BOLT	OE202
11	1	LOCK WASHER	OC31
12	2	NUT	OB26
13	1	LOCK WASHER	OC31
14	1	PIVOT BRACKET	1E43
15	1	BOLT	OE204
16	2	BOLT	OE201
17	1	WIRE ASSEMBLY	2E405
18	1	WIRE ASSEMBLY	2E401
19	1	OIL PRESSURE SWITCH	2E206
20	1	WIRE ASSEMBLY	2E400
21	1	V-BELT	2B209






KEY	PART NO.	DESCRIPTION
	510-859	ALTERNATOR
	505-37	VOLTAGE REGULATOR
A	514-139	REAR COVER
B	--	CONNECTOR CLIP
C	501-43	BRIDGE ASSEMBLY
D	--	BRUSH COVER (ONLY)
E	503-12	BRUSH HOLDER ASSEMBLY
F	515-7	TERNINAL/BACKET
G	--	REAR FOOT
H	514-212	REAR HOUSING ASSEMBLY
I	511-4	BEARING RETAINER (ONLY)
J	513-20	STATOR
K	512-45	ROTOR ASSEMBLY
L	NA	SPACER
M	11-23	REAR BEARING
N	11-21	FRONT BEARING
O	511-11	BEARING RETAINER (ONLY)
P	514-141	FRONT HOUSING ASSEMBLY
Q	520-92	THROUGH BOLTS (4)
R	507-55	FAN
S	507-101	PULLEY
T	--	SPACER
U	520-141	INSTALLATION KIT
V	--	GROUND TERMINAL ASSEMBLY
W	520-100	INS. TERMINAL ASSEMBLY
X	--	CAPACITOR
Y	--	B+ INSULATOR
Z	--	STUD

## ENGINE SUPPORTS




KEY	ENGINE	QUAN	CODE	PART NO.	DESCRIPTION
1	ALL	1	L	D660	ENGINE SUPPORTS (SET OF 4)
2	ALL	1	L	1A407	SUPPORT, LEFT REAR (528)
3	ALL	1	L	1A406	SUPPORT, RIGHT REAR (626)
4	ALL	1	L	1A329	SUPPORT, RIGHT FRONT (600)
5	ALL	1	L	1A330	SUPPORT, LEFT FRONT (610)
6	ALL	2	L	OC31	LOCKWASHER, 5/16"
7	ALL	2	L	OE201	BOLT, 5/16-18 x 3/4"
8	ALL	9	L	OE403	BOLT, 7/16-14 x 1 1/4"
9	ALL	9	L	OC51	LOCKWASHER, 7/16"
10	ALL	4	L	OE303-C	BOLT, 3/8-16 x 1 1/4"
11	ALL	4	L	OC41	LOCKWASHER, 3/8"



<u>KEY</u>	<u>QUANTITY</u>	<u>DESCRIPTION</u>	<u>LEHMAN NUMBER</u>
1	1	FLYWHEEL HOUSING	1A392
2	1	DAMPER	2L7
3	1	FLYWHEEL INERTIA RING)	
4	1	FLYWHEEL )	
5	1	DOWEL )	
6	1	DOWEL )	
7	6	LOCK WASHER )	
8	6	BOLT )	
9	3	LOCK WASHER	0C31
10	3	BOLT	0E201C
11	2	DOWEL	2K207
12	14	LOCK WASHER	0C51
13	14	BOLT	0E403
14	1	BOLT	0E405
15	1	LOCK WASHER	0C51
16	2	DOWEL	2K207


ONE ASSEMBLY

1A415




## EK31 and EK32 ALARM SYSTEMS


<u>CODE</u>	<u>PART</u>	<u>DESCRIPTION</u>
L	EG302	OIL ALARM SENDING UNIT, 1/8" NPT
L	3G9	BUSHING, 1/8 x 3/8 NPT
L	EG403	ALARM TEMPERATURE SENDER, 3/8" NPT
L	EI600	RELAY
L	EI601	BUZZER



TEMP SENDER




RELAY




OIL SENDER

BUSHING



BUZZER



FUEL LINE CONNECTOR

2

ENGINE	QUAN	CODE	PART NO.	DESCRIPTION
ALL	1	L	D798	FUEL LINE, 9" LONG (INCLUDES KEY 2)
ALL	1	L	D799	FUEL LINE, 15" LONG (INCLUDES KEY 2)
ALL	1	L	D799-AA	FUEL LINE, 36" LONG
ALL	1	L	3E18	NUT, FUEL LINE

## D1496.A WATER HEATER CONNECTION KIT

KEY	QUAN	PART NO.	DESCRIPTION
1	1	D1496.A	WATER HEATER CONNECTION KIT
2	2	3G24	HOSE BARB
3	2	3E498	ADAPTOR
4	2	3F12	TEE

## "ON BOARD" SPARE PARTS KITS

The prudent boatman will stow spare engine parts aboard his vessel to be used in the event of emergency.

Ordinarily it is not practical to perform major engine repairs on a small vessel at sea, but such parts as hoses, vee belts, filter elements, etc. which may be serviced and which, upon failure, could cause engine failure, should certainly be carried aboard. For this purpose the following "Limited Cruising Kits" are offered.

For the vessel that may range to distant or foreign ports away from lines of communication or transportation, consideration should be given to stowage of additional parts. For such use the "Extended Cruising Range Kits" are available.

LIMITED CRUISING RANGE KITS include: complete set of fuel injection pipes; thermostat; end gaskets for manifold and exchanger; zinc pencil element; raw water pump impeller; lube oil filter element; fuel filter element; vee belt; complete set of hoses.

KIT No. 115 for SD80/SP90

KIT No. 117 for SD120/SP135

KIT No. 119 for SP160

KIT No. 121 for SP225

EXTENDED CRUISING RANGE KITS include: All parts as listed above for limited cruising range kits except for raw water pump impeller and fuel lift pump rebuild kit. Additional items include: complete gasket (overhaul) set (excepting transmission); complete injector; injector removal tool; complete fresh water pump; complete fuel supply (lift) pump; raw water pump overhaul kit.

KIT No. 116 for SD80/SP90

KIT No. 118 for SD120/SP135

KIT No. 120 for SP160

KIT No. 122 for SP225

## MANUALS, PARTS LISTS, Etc.

PART NO.	DESCRIPTION
4C90	FORD ENGINE REBUILDING (SHOP) MANUAL Volume 1
4C90A	FORD ENGINE MANUAL Volume 2 (Electrical)
4C70	PARAGON P30 & P40 SERIES (LEHMAN 155 & 156
4C71	WARNER 71 (LEHMAN 71) TRANSMISSION ONLY
4C72	WARNER 72 (LEHMAN 72) TRANSMISSION ONLY
4C73	WARNER 73 (LEHMAN 73) TRANSMISSION (DIRECT DRIVE & REDUCTION)
4C74	WARNER 1.5 REDUCTIONS ONLY
4C75	WARNER 1.9 REDUCTIONS ONLY
4C76	WARNER 2.1 REDUCTIONS ONLY
4C77	WARNER 2.5 & 2.9 REDUCTIONS ONLY
4C78	WARNER VEE DRIVE (ALL RATIOS)
4C79	WARNER DROP CENTER (LEHMAN 161 & 162) TRANSMISSION & REDUCTIONS
4C80	WARNER GENERAL INSTALLATION MANUAL